

Large Synoptic Survey Telescope (LSST) Data Management

LSST Database Baseline Schema

Colin Slater, Fritz Mueller, Brian Van Klaveren, Jacek Becla

LDM-153

Latest Revision: 2019-06-27

This LSST document has been approved as a Content-Controlled Document by the LSST DM Change Control Board. If this document is changed or superseded, the new document will retain the Handle designation shown above. The control is on the most recent digital document with this Handle in the LSST digital archive and not printed versions. Additional information may be found in the corresponding DM RFC.



LDM-153

Change Record

Version	Date	Description	Owner name		
1	2007-01-12	Initial Version.	Jacek Becla		
2	2007-02-14	General edits.	Jacek Becla		
3	2007-02-21	General edits.	Jacek Becla		
4	2007-02-27	General edits.	Jacek Becla		
5	2007-03-05	General edits.	Jacek Becla		
6	2007-03-07	General edits.	Jacek Becla		
7	2007-04-09	General edits.	Jacek Becla		
8	2007-09-05	General edits.	Jacek Becla		
9	2011-07-04	General edits. Jacek Becla			
10	2011-07-14	General edits. Jacek Becla			
11	2013-08-02	Major refresh of the schema to reflect sci-	Jacek Becla, Kian-Tat		
		ence requirements described in Data Prod-	Lim		
		ucts doc. Added sections about schema evo-			
		lution, provenance			
12	2013-09-30	Resynchronized with the latest Data Products	Jacek Becla		
		Definition Document (v Sep 23 2013) and cor-			
		responding schema.			
13	2013-10-10	TCT approved	R. Allsman		
14	2013-10-18	Fixed Table of Contents	Jacek Becla		
15	2019-06-27	Switch to yaml-defined schema	Colin Slater		

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Contents

1	Sche	ema Format and Documentation	1
2	Stor	ed Procedures and Functions	1
3	Sele	cted Catalogs	2
	3.1	Core Catalogs	2
		3.1.1 Sizes	3
		3.1.2 Partitioning	4
		3.1.3 Diagram	4
	3.2	Metadata Catalogs	5
		3.2.1 Sizes	6
		3.2.2 Diagram	6
	3.3	Provenance	6
		3.3.1 Size	6
		3.3.2 Diagrams	8
	3.4	Other Tables	8
4	Sele	cted Design Aspects	11
	4.1	Provenance	11
	4.2	Schema Evolution	13
		4.2.1 Released Data Sets	13
		4.2.2 Level 1 (Up-to-date Catalog)	14
5	Nam	ning Conventions	14
6	Base	eline Schema	15
	6.1	ZZZ_Schema_Description	15
	6.2	DiaObject	15
	6.3	SSObject	21
	6.4	DiaSource	24
	6.5	DiaForcedSource	31



6.6	DiaObject_To_Object_Match	32
6.7	Object	32
6.8	Object_Extra	49
6.9	Object_APMean	50
6.10	Object_Periodic	50
6.11	Object_NonPeriodic	51
6.12	Source	51
6.13	Source_APMean	54
6.14	ForcedSource	54
6.15	RawAmpExposure	55
6.16	RawAmpExposureMetadata	56
6.17	RawCcdExposure	56
6.18	RawCcdExposureMetadata	58
6.19	RawExposure	58
6.20	CcdVisit	59
6.21	CcdVisitMetadata	61
6.22	Visit	61
6.23	VisitMetadata	63
6.24	Visit_To_RawExposure	63
6.25	prv_ProcHistory	63
6.26	prv_Pipeline	64
6.27	prv_cnf_Pipeline	64
6.28	prv_Task	65
6.29	prv_cnf_Pipeline_Tasks	65
6.30	prv_cnf_Task	65
6.31	prv_cnf_Task_Columns	66
6.32	prv_cnf_Task_Files	66
6.33	prv_cnf_Task_KVParams	67
6.34	prv_Node	67
6.35	prv_cnf_Node	67

LDM-153

Latest Revision 2019-06-27



6.36	prv_DataBlock	68
6.37	prv_RowldToDataBlock	68
6.38	prv_TaskExecution	69
6.39	prv_TaskExecutionToInputDataBlock	69
6.40	prv_TaskExecutionToOutputDataBlock	70
6.41	sdqa_lmageStatus	70
6.42	sdqa_Metric	70
6.43	sdqa_Rating_ForAmpVisit	71
6.44	sdqa_Rating_CcdVisit	71
6.45	sdqa_Threshold	72
6.46	LeapSeconds	72
6.47	ApertureBins	73

LDM-153

Latest Revision 2019-06-27

LSST Database Baseline Schema

LDM-153



LSST Database Baseline Schema

1 Schema Format and Documentation

The LSST Database schema master files are stored in yaml files which are designed to be read by the "Felis"¹ schema manipulation tool. The files live in the cat package and are versioncontrolled via git together with the rest of the LSST software.

The yaml files are designed to contain both the required attributes necessary for instantiating a database table and extra per-column metadata for enabling a richer description of the data, such as additional descriptive text, physical units, or IVOA UCDs. The choice of a yaml format also enables additional metadata attributes to be added as the need arises during development.

The schema tables presented in this document are automatically generated from the yaml files in the cat package.

2 Stored Procedures and Functions

We maintain a small set of stored procedures and functions, as well as a set of user-defined functions (UDFs). Since stored procedures and functions typically are vendor-specific, we have tried to limit them to the bare minimum; nevertheless, we now have ~ 10 such procedures, most related to converting different time formats. The most frequently used functions are written as native user-defined functions for performance and portability reasons. They include support for spherical geometry, photometry conversions, and statistical functions (e.g., median). These spatial functions rely on custom HTM indices to allow fast spatial selections, such as point in circle, polygon or ellipse searches. We are collaborating with the team from Johns Hopkins University that implemented HTM indexing and UDFs for SDSS, and we already incorporated many of their lessons learned into our UDFs (their UDFs were written in C# for SQL Server, since then the SDSS team converted them to C++ using automated conversion tools.)

Since these UDFs are not LSST-specific and may be of broader interest (to MySQL community and beyond), we maintain them as an open-source project independent from LSST. This project, SciSQL, is hosted at https://github.com/smonkewitz/scisql.

¹https://github.com/lsst-dm/felis/

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

3 Selected Catalogs

The baseline schema is driven primarily by the Data Products Definitions Document (DPDD). The schema can be divided into several logical groups:

- Core Catalogs
- Metadata Catalogs
- Provenance Catalogs
- SDQA

Here, a catalog refers to a group of closely-related tables that act as a unified dataset from an end user's point of view.

3.1 Core Catalogs

The core catalogs can be divided into:

- Level 1 Catalogs: DiaObject, SSObject. DiaSource and DiaForcedSource.
- Level 2 Catalogs: Object, Source, ForcedSource.

DiaObject table contains information about astronomical objects measured on difference images. For reproducibility reasons (described in LDM-135, chapter 3.1), we expect to create a new row each time there is an update to a diaObject, thus the total number of rows in that table is higher than the unique number of diaObjects.

SSObject table contains information about Solar System (also called moving) objects.

DiaSource table contains information about individual measurements of astronomical objects on different images.

DiaForcedSource contains photometry measurements about low signal-to-noise detections done on individual difference image exposures in each place where an object was detected on a previous difference image within one month.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Object Catalog contains information about static astronomical objects measured on a stacked image. It is the most commonly used catalog.

Source Catalog contains information about high signal-to-noise (>5 sigma) detections on single frame images.

ForcedSource table contains photometry measurements about low signal-to-noise detections done on individual exposures in each place where an object was detected on a stacked image. Due to the nature of these detections only a few parameters can be measured, thus the table is very narrow, however it is by far the largest in terms of row-count.

DiaObject_To_Object_Match table keeps a mapping of diaObjects to nearby objects, used primarily for user data analysis. For rapid real-time queries we maintain three nearbyObj columns in DiaObject.

3.1.1 Sizes

The table below provides a rough count (size, rows, columns) for core tables (in the last Data Release, counting data only, e.g., size of persistent overheads such as indices is not reflected here). The exact numbers for each DR can be found in LDM-141.

Table	Size [TB]	Rows [billions]	Columns
Object (narrow)	~ 107	~ 47	~ 330
Object (all extras)	~ 1,200	Largest $\sim 1,500$	$\sim 7,650$
Source	$\sim 5,000$	~ 9,000	~ 50
ForcedSource	~ 1,900	~ 50,000	6
SSObject	~ 0.003	0.006	~ 80
DiaObject	~ 27 (76 max)	~ 15 unique (~ 44 max)	~ 260
DiaSource	~ 23	~ 45	~ 70
DiaForcedSource	~ 13	~ 300	8

We expect to keep refining the baseline schema extensively through LSST's construction, and will likely end up adding a small number of additional columns we haven't thought about so far. Since the schema is used for cost estimation, such changes would increase overall size of the database (and consequently, the cost), so we have reserved in the costing model (LDM-141) 25% of each table size² for yet-unknown columns. Further, the costing model assumes

²With the exception of ForcedSource and DiaForcedSource



a 3% increase in row size for each Data Release.

3.1.2 Partitioning

To optimize disk I/O and ensure frequently accessed columns are collocated, and to avoid unnecessary I/O, selected Catalogs are *vertically partitioned*.

The Object Catalog is partitioned vertically into the following tables:

- Object a table with ~330 most frequently used columns. This table is expected to contain ~47 billion rows by the end of the survey, containing ~48% in the first data release.
- Object_APMean a very narrow table containing aperture photometry mean values, on average ~8 per object.
- Object_Periodic a very narrow table containing definitions of periodic features, on average ~32 per object.
- Object_NonPeriodic a very narrow table containing definitions of non-periodic features, on average ~20 per object.
- Object_Extra a very wide table with remaining, less frequently used columns, such as covariances for 2 models (Point Source and Bulge+Disk), and Bulge+Disk samples. These are packed into 3 blobs, 66, 168, and 7,200 elements in each blob respectively. Packing is driven by expected access pattern: entire set of elements in a blob or nothing will be accessed. There will be one such row for each row in the Object table.

The Source Catalog consists of two tables: Source and Source_APMean, the latter is similar to Object_APMean.

Since managing trillions of rows in a single table is close to impossible, in addition to vertical partitioning, all core catalogs will be horizontally partitioned, The Level 1 catalogs will be partitioned by time into a small set of tables, and all large Level 2 catalogs will be partitioned spatially into ~20,000 partitions for each table. Further details related to horizontal partitioning of these tables are discussed in LDM-135 (*LSST Database Design*).

3.1.3 Diagram

The diagram below depicts all core tables, and their relations.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.







3.2 Metadata Catalogs

Metadata catalogs contains information about LSST "raw exposures" and "science calibrated visits". Information is tracked at different levels:

- focal plane (entire exposure/visit),
- raft (raft = 9 ccds)
- ccd (there are 189 ccds per focal plane)
- amp (there are 16 amplifiers per ccd).

When appropriate, we denormalize information into "lower-level" table (eg, information from ccd-level is repeated for each amp) to avoid extraneous joins for common accesses.

In addition to fully structured tables, for selected tables we expect to maintain an additional table with key-value pairs. This will allow us to introduce additional "columns" without altering corresponding table's schema (at the cost of degraded performance). This might be particularly handy when trying to determine what information would be particularly useful to

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

derive from the existing columns. Periodically, most commonly used key-value pairs will be converted into regular columns.

In addition, we maintain a table that maps raw exposures to visits. Typically it will contain two rows for each visit.

3.2.1 Sizes

Size of the metadata tables is not posing any major challenge. LSST is expected to produce \sim one thousand visits per night, which leads to \sim 3 million visits during 10 year lifetime of the survey.

3.2.2 Diagram

The diagram below depicts the metadata tables, and their relations.

3.3 Provenance

In LSST, we define Provenance as execution trace, or in other words information "how we came up with the data". Provenance will be used primarily:

- to help with data QA, for example to detect which parts of data were affected by a faulty algorithm or a bad node,
- as a recipe how to regenerate intermediate results.

Specifically, Provenance is responsible for capturing configuration of:

- software (which pipelines were run on given data, what processing stages were part of each pipeline, what versions of algorithms were used, how was processing parallelized and on which computing node each piece was executed etc) and
- hardware (what was the configuration of focal plane, each raft, ccd, amplifier, filter etc).

3.3.1 Size

In terms of size, we expect provenance to be a very small fraction of the entire data set. The largest contribution is an 8-byte column we are adding for every core tables (with the ex-

The contents of this document are subject to configuration control by the LSST DM Change Control Board.









LDM-153

ception of DiaForcedSource table, as it will have the same provenance as its corresponding DiaSource table), and selected metadata tables. Note that in some cases, in particular for the very narrow ForcedSource table with trillions of rows, that contribution is non-negligible.

3.3.2 Diagrams

The diagram below depicts the metadata tables, and their relations. Note that there is a separate section discussing provenance design in details, see below *Selected Design Aspects* below.



FIGURE 3: Provenance table relationships

3.4 Other Tables

In addition to the catalogs/tables described above, there are several groups of other tables in the baseline schema. In terms of size and complexity they pose very little challenge comparing to the catalogs described above, thus this document does not focus on discussing these tables (and we have left designing details of these tables for closer-to-commissioning). They include Software Data quality Assurance tables (prefixed with sdqa_), used for tracking various quality aspects of the LSST catalogs.



LDM-153



FIGURE 4: Hardware provenance table relationships

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Latest Revision 2019-06-27



FIGURE 5: Software provenance table relationships

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



4 Selected Design Aspects

Below we covered in details selected, most interesting aspects of the schema design.

4.1 Provenance

Provenance is fundamentally concerned with two things: recording the state of relevant portions of the system and associating state with the generation of an output from inputs. Given the size of data, provenance information cannot be captured per data element. Instead data elements with the same provenance should be grouped. That in turn is non-trivial due to the way data elements will be built and updated:

- Any given data element will be the result of the processing of raw data by a Task Graph (also called a pipeline). Each Graph consists of many Tasks. Each task may involve executing multiple algorithms.
- It is anticipated we will need to fix bad data (as long as it is unreleased) by reprocessing it (e.g. using a fixed algorithm), so in practice different parts of the same data element might have many different processing histories.
- Finally, there is a large number of dependencies. Here is just a small example: object data depends on a coadd, which is generated using masks derived from difference sources which depend on the corresponding difference image which depends on a template image which depends on calibrated science images and so on...

Also, provenance should be flexible enough to easily allow adding new items to the system state.

For the above reasons, simple solutions like timestamping every data element will not work.

In practice, we plan to implement the state recording function of Provenance using time ranges, with granularity up to 1 sec. Every configurable piece of information will be tracked through two tables: one that keeps definitions and the other that keeps configurations. For example, each filter (u, g, r, i, z, y) will be represented as one row in prv_Filter table (there will be exactly 6 definitions), and each configuration of each filter will be represented as one row in prv_cnf_Filter table (initially there will be 6 configurations: one for each filter, but if we happen to later break one filter and will introduce a new one, a new configuration will need

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

to be inserted). Each configuration will have a validity time range assigned (time period when it was valid).

The heart of the processing recording function of Provenance is the *prv_ProcHistory* table; it has two responsibilities:

- Assign a unique processing history id (procHistoryld) for each creation of a set of output data elements. An 8-byte integer is sufficient to provide the needed granularity.
- Bind each unique procHistoryld with a set of executions of tasks, including the inputs to those tasks, identified by their own procHistorylds. (A task is the smallest chunk that will be executed atomically, that is, if part of a task fails, the whole task will be rolled back and re-run). Typically there will be one task execution for each procHistoryld, but in cases of reprocessing there may be more than one.

Notice that procHistoryld is not associated with a time range, but with a set of task executions, each having its own configuration, its own time range, and its own node it runs on.

The Provenance may also track which columns for each table are updated by each stage (we require that each column is updated by a single stage only - for that reasons some columns, eg. flags had to be split into multiple columns).

Every data element that needs to have provenance tracked (for example, every row in the Object, Source, or Exposure table) will need to store a procHistoryld. Note that a single row might be generated or updated by different pipelines or task graphs, and each may run at different time, on different hardware, possibly even at a different site. Having a procHistoryld will allow it to find which task graphs and tasks were executed for it, at what time, and on which processing nodes. It will then be possible to correlate the time periods when each task was executed with the configurations that were valid at those times.

Such an approach has two important pros:

• **Flexibility**: It allows us to decouple configurable elements from Objects, Sources, Exposures, etc. — they are very loosely coupled through time range only. In particular, it means that new configurable items can be added or removed from the system at any given time with no need to do schema evolution and no need to update existing data.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

• **Space-efficiency**: It is clear that components of the system will be changing relatively frequently. Minimizing the storage required to track these changes is essential. In our case, a new configuration will only require storage for that configuration. Each Object/Source/Exposure only needs to store one procHistoryld to get access to hundreds of different configurations.

We expect we will need to tune the current approach to provide efficient query access to the Provenance. In particular, the implementation relies on range queries which may need special optimizations, or special indexes.

4.2 Schema Evolution

In summary, we expect to avoid heavy changes that alter shape of large tables (e.g. by preallocating space), and rely on partitioning to scale and run necessary schema changes fast and scalably in parallel³.

4.2.1 Released Data Sets

Each data release is independent, therefore the database schema can easily change between data releases; we do not anticipate any non-trivial challenges here.

Adding new columns. We are planning to keep a few extra unused columns of each common type (for example, 3 FLOATs, 3 DOUBLES, 3 INTs, 3 BIGINTs) for each large table, and use one of them when a new column is needed. (renaming a column is a trivial and instantaneous operation). Speed of filling new columns should be comparable to speed of a full table scan.

Updating existing columns. Speed of updating values should be comparable to speed of a single shared scan.

Deleting columns. If we have to delete a column, instead of deleting it, (which is expensive as it changes shape of a table), we will add it to the pool of "extra, unused columns" by renaming it.

The unsed/hidden columns will be hidden through non-materialized views. It is likely that we will end up providing multiple views, e.g. each time we make a schema change, we'd expose the changes through a new view.

³For more information about the schema evolution tests we run, refer to https://dev.lsstcorp.org/trac/wiki/db/tests/SchemaEvolution

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Non-trivial changes. Should we ever need to do non-trivial changes: Non trivial schema changes on multi-billion row table tend to take extremely long time (measured in days). In our case, each large table will be partitioned into several thousand chunks, which makes the updates scalable and faster: not only the updates can be done in parallel on multiple machines, but each partition is small enough to be handled efficiently without running into any bottlenecks or problems with lack of buffer space.

Notes on administration. All queries accessing the database will go through our interface, which intercepts and interprets the queries. This will allow us to put the entire system in special mode (user queries will be queued, administrative queries will continue to work). The administrative tools we are building will allow us to push the necessary updates to all nodes, and we could use the existing scheduling mechanisms to run the upgrade in the most efficient fashion. The admin tools will also allow running necessary verifications (e.g., whether the schema for all table chunks matches).

4.2.2 Level 1 (Up-to-date Catalog)

We will have opportunity to update schema every time we are replacing Level 1 catalog after each data release. Should we need to make the updates in between, the changes can easily be done during the time when we are not taking data (daytime).

5 Naming Conventions

We have defined a set of naming convention for naming tables, columns and relationships. In summary, the format of table names follows:

```
<_><prefix><purpose>_<extend>_<component><postfix>
```

Leading _ is used to show it is an internal table.

Prefix:

 All Provenance tables are prefixed with prv_, example: prv_Amp. Further, it may be followed by cnf_ which is used for provenance tables containing individual configurations. For example, one row in prv_Ccd contains information about one particular Ccd, and prv_cnf_Ccd contains information about one specific configuration version of one particular Ccd.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Purpose: it includes things like Raw, Science, Calibration, Bias, Dark, Flat, Fringe, IR. (we have recently dropped "Science" for *Visit tables).

Extend: Fpa, Ccd, Amp (we have dropped "Fpa" from raw and science table names).

Component: Exposure, Object, Source, Psf, Wcs...

Postfix: optional

Mapping tables follows its own naming scheme: __To_

6 Baseline Schema

This schema corresponds to git commit 82029d8 in the cat package.

6.1 ZZZ_Schema_Description

Internal table used for storing schema version and description.

Table 1: ZZZ_Schema_Description Table

Column Name	Data type Unit	Description [UCD]
version	string	The schema version.
descr	string	Description of the schema.

6.2 DiaObject

The DiaObject table contains descriptions of the astronomical objects detected on one or more difference images.

Table 2:	DiaObject	Table
----------	-----------	-------

Column Name	Data type Unit	Description [UCD]
diaObjectId	long	Unique id. [meta.id; src]
validityStart	timestamp	Time when validity of this diaObject starts.
validityEnd	timestamp	Time when validity of this diaObject ends.
		Continued on payt page



LDM-153

Column Name	Data type	Unit	Description [UCD]
ra	double	deg	RA-coordinate of the position of the object at time
			radecTai. [pos.eq.ra]
raSigma	float	deg	Uncertainty of ra. [stat.error; pos.eq.ra]
decl	double	deg	Decl-coordinate of the position of the object at
			time radecTai. [pos.eq.dec]
declSigma	float	deg	Uncertainty of decl. [stat.error; pos.eq.dec]
ra_decl_Cov	float	deg ²	Covariance between ra and decl.
radecTai	double		Time at which the object was at a position ra/decl.
			[time.epoch]
pmRa	float	mas/yr	Proper motion (ra). [pos.pm]
pmRaSigma	float	mas/yr	Uncertainty of pmRa. [stat.error; pos.pm]
pmDecl	float	mas/yr	Proper motion (decl). [pos.pm]
pmDeclSigma	float	mas/yr	Uncertainty of pmDecl. [stat.error; pos.pm]
parallax	float	mas	Parallax. [pos.parallax]
parallaxSigma	float	mas	Uncertainty of parallax. [stat.error; pos.parallax]
pmRa_pmDecl_Cov	float	(mas/yr) ²	Covariance of pmRa and pmDecl. [stat.covariance; pos.eq]
pmRa_parallax_Cov	float	mas ² /yr	Covariance of pmRa and parallax.
			[stat.covariance]
pmDecl_parallax_Co	V		
	float	mas²/yr	Covariance of pmDecl and parallax.
			[stat.covariance]
pmParallaxLnL	float		Natural log of the likelihood of the linear proper
			motion parallax fit. [stat.likelihood]
pmParallaxChi2	float		Chi ² static of the model fit. [stat.fit.chi2]
pmParallaxNdata	int		The number of data points used to fit the model.
uPSFluxMean	float	nmgy	Weighted mean point-source model magnitude
			for u filter. [phot.count]
uPSFluxMeanErr	float	nmgy	Standard error of uPSFluxMean. [stat.error]
uPSFluxSigma	float	nmgy	Standard deviation of the distribution of uPSFlux.
			[stat.stdev]

Table 2: DiaObject Table



LDM-153

Table 2: DiaObject Table

Column Name	Data type	Unit	Description [UCD]
uPSFluxChi2	float		Chi ² statistic for the scatter of uPSFlux around uPS-
			FluxMean. [stat.fit.chi2]
uPSFluxNdata	int		The number of data points used to compute uPS-
			FluxChi2.
uFPFluxMean	float	nmgy	Weighted mean forced photometry flux for u filter. [phot.count]
uFPFluxMeanErr	float	nmgy	Standard error of uFPFluxMean. [stat.error]
uFPFluxSigma	float	nmgy	Standard deviation of the distribution of uFPFlux. [stat.stdev]
gPSFluxMean	float	nmgy	Weighted mean point-source model magnitude for g filter. [phot.count]
gPSFluxMeanErr	float	nmgy	Standard error of gPSFluxMean. [stat.error]
gPSFluxSigma	float	nmgy	Standard deviation of the distribution of gPSFlux.
			[stat.stdev]
gPSFluxChi2	float		Chi ² statistic for the scatter of gPSFlux around gPS-
			FluxMean. [stat.fit.chi2]
gPSFluxNdata	int		The number of data points used to compute gPS-
			FluxChi2.
gFPFluxMean	float	nmgy	Weighted mean forced photometry flux for g filter. [phot.count]
gFPFluxMeanErr	float	nmgy	Standard error of gFPFluxMean. [stat.error]
gFPFluxSigma	float	nmgy	Standard deviation of the distribution of gFPFlux. [stat.stdev]
rPSFluxMean	float	nmgy	Weighted mean point-source model magnitude
			for r filter. [phot.count]
rPSFluxMeanErr	float	nmgy	Standard error of rPSFluxMean. [stat.error]
rPSFluxSigma	float	nmgy	Standard deviation of the distribution of rPSFlux.
			[stat.stdev]
rPSFluxChi2	float		Chi ² statistic for the scatter of rPSFlux around rPS-
			FluxMean. [stat.fit.chi2]
rPSFluxNdata	int		The number of data points used to compute rPS-
			FluxChi2.



LDM-153

Column Name	Data type	Unit	Description [UCD]
rFPFluxMean	float	nmgy	Weighted mean forced photometry flux for r filter.
			[phot.count]
rFPFluxMeanErr	float	nmgy	Standard error of rFPFluxMean. [stat.error]
rFPFluxSigma	float	nmgy	Standard deviation of the distribution of rFPFlux. [stat.stdev]
iPSFluxMean	float	nmgy	Weighted mean point-source model magnitude for i filter. [phot.count]
iPSFluxMeanErr	float	nmgy	Standard error of iPSFluxMean. [stat.error]
iPSFluxSigma	float	nmgy	Standard deviation of the distribution of iPSFlux. [stat.stdev]
iPSFluxChi2	float		Chi ² statistic for the scatter of iPSFlux around iPS- FluxMean. [stat.fit.chi2]
iPSFluxNdata	int		The number of data points used to compute iPS- FluxChi2.
iFPFluxMean	float	nmgy	Weighted mean forced photometry flux for i filter. [phot.count]
iFPFluxMeanErr	float	nmgy	Standard error of iFPFluxMean. [stat.error]
iFPFluxSigma	float	nmgy	Standard deviation of the distribution of iFPFlux. [stat.stdev]
zPSFluxMean	float	nmgy	Weighted mean point-source model magnitude for z filter. [phot.count]
zPSFluxMeanErr	float	nmgy	Standard error of zPSFluxMean. [stat.error]
zPSFluxSigma	float	nmgy	Standard deviation of the distribution of zPSFlux. [stat.stdev]
zPSFluxChi2	float		Chi ² statistic for the scatter of zPSFlux around zPS- FluxMean. [stat.fit.chi2]
zPSFluxNdata	int		The number of data points used to compute zPS- FluxChi2.
zFPFluxMean	float	nmgy	Weighted mean forced photometry flux for z filter. [phot.count]
zFPFluxMeanErr	float	nmgy	Standard error of zFPFluxMean. [stat.error]

Table 2: DiaObject Table



LDM-153

Column Name	Data type	Unit	Description [UCD]			
zFPFluxSigma	zFPFluxSigma float		Standard deviation of the distribution of zFPFlux.			
			[stat.stdev]			
yPSFluxMean	float	nmgy	Weighted mean point-source model magnitude			
			for y filter. [phot.count]			
yPSFluxMeanErr	float	nmgy	Standard error of yPSFluxMean. [stat.error]			
yPSFluxSigma	float	nmgy	Standard deviation of the distribution of yPSFlux. [stat.error]			
yPSFluxChi2	float		Chi ² statistic for the scatter of yPSFlux around yPS- FluxMean. [stat.fit.chi2]			
yPSFluxNdata	int		The number of data points used to compute yPS- FluxChi2.			
yFPFluxMean	float	nmgy	Weighted mean forced photometry flux for y filter. [phot.count]			
yFPFluxMeanErr	float	nmgy	Standard error of yFPFluxMean. [stat.error]			
yFPFluxSigma	float	nmgy	Standard deviation of the distribution of yFPFlux.			
			[stat.stdev]			
uLcPeriodic	binary		Periodic features extracted from light-curves using			
			generalized Lomb-Scargle periodogram for u filter. [32 FLOAT].			
gLcPeriodic	binary		Periodic features extracted from light-curves using			
			generalized Lomb-Scargle periodogram for g filter. [32 FLOAT].			
rLcPeriodic	binary		Periodic features extracted from light-curves using			
			generalized Lomb-Scargle periodogram for r filter. [32 FLOAT].			
iLcPeriodic	binary		Periodic features extracted from light-curves using			
			generalized Lomb-Scargle periodogram for i filter. [32 FLOAT].			
zLcPeriodic	binary		Periodic features extracted from light-curves using			
			generalized Lomb-Scargle periodogram for z filter. [32 FLOAT].			

Table 2: DiaObject Table



LDM-153

Table 2: DiaObject Table

Column Name	Data type	Unit	Description [UCD]				
yLcPeriodic	binary		Periodic features extracted from light-curves using generalized Lomb-Scargle periodogram for y filter. [32 FLOAT].				
uLcNonPeriodic	binary		Non-periodic features extracted from light-curves using generalized Lomb-Scargle periodogram for u filter. [20 FLOAT].				
gLcNonPeriodic	binary		Non-periodic features extracted from light-curves using generalized Lomb-Scargle periodogram for g filter. [20 FLOAT].				
rLcNonPeriodic	binary		Non-periodic features extracted from light-curves using generalized Lomb-Scargle periodogram for r filter. [20 FLOAT].				
iLcNonPeriodic	binary		Non-periodic features extracted from light-curves using generalized Lomb-Scargle periodogram for i filter. [20 FLOAT].				
zLcNonPeriodic	binary		Non-periodic features extracted from light-curves using generalized Lomb-Scargle periodogram for z filter. [20 FLOAT].				
yLcNonPeriodic	binary		Non-periodic features extracted from light-curves using generalized Lomb-Scargle periodogram for y filter. [20 FLOAT].				
nearbyObj1	long		ld of the closest nearby object. [meta.id; src]				
nearbyObj1Dist	float	arcsec	Distance to nearbyObj1.				
nearbyObj1LnP	float		Natural log of the probability that the observed diaObject is the same as the nearbyObj1.				
nearbyObj2	long		Id of the second-closest nearby object. [meta.id; src]				
nearbyObj2Dist	float	arcsec	Distance to nearbyObj2.				
nearbyObj2LnP	float		Natural log of the probability that the observed diaObject is the same as the nearbyObj2.				
nearbyObj3	long		Id of the third-closest nearby object. [meta.id; src]				
nearbyObj3Dist	float	arcsec	Distance to nearbyObj3.				



LDM-153

Table 2: DiaObject Table

Column Name	Data type	Unit	Description [UCD]
nearbyObj3LnP	float		Natural log of the probability that the observed
			diaObject is the same as the nearbyObj3.
flags	long		Flags, bitwise OR tbd. [meta.code]
htmld20	long		HTM index.

6.3 SSObject

The SSObject table contains description of the Solar System (moving) Objects.

Column Name	Data type Unit	Description [UCD]
ssObjectId	long	Unique identifier. [meta.id; src]
q	double	Osculating orbital elements at epoch (q, e, i, lan, aop, M, epoch).
qSigma	double	Uncertainty of q. [stat.error]
е	double	Osculating orbital elements at epoch (q, e, i, lan, aop, M, epoch).
eSigma	double	Uncertainty of e. [stat.error]
i	double	Osculating orbital elements at epoch (q, e, i, lan, aop, M, epoch).
iSigma	double	Uncertainty of i. [stat.error]
lan	double	Osculating orbital elements at epoch (q, e, i, lan, aop, M, epoch).
lanSigma	double	Uncertainty of lan. [stat.error]
аор	double	Osculating orbital elements at epoch (q, e, i, lan, aop, M, epoch).
aopSigma	double	Uncertainty of aop. [stat.error]
Μ	double	Osculating orbital elements at epoch (q, e, i, lan, aop, M, epoch).
MSigma	double	Uncertainty of M. [stat.error]
epoch	double	Osculating orbital elements at epoch (q, e, i, lan, aop, M, epoch).

Table 3: SSObject Table



LDM-153

Column Name	Data type	Unit	Description [UCD]				
epochSigma	double		Uncertainty of epoch. [stat.error]				
q_e_Cov	double	Covariance of q and e. [stat.covariance]					
q_i_Cov	double	Covariance of q and i. [stat.covariance]					
q_lan_Cov	double		Covariance of q and lan. [stat.covariance]				
q_aop_Cov	double		Covariance of q and aop. [stat.covariance]				
q_M_Cov	double		Covariance of q and M. [stat.covariance]				
q_epoch_Cov	double		Covariance of q and epoch. [stat.covariance]				
e_i_Cov	double		Covariance of e and i. [stat.covariance]				
e_lan_Cov	double		Covariance of e and lan. [stat.covariance]				
e_aop_Cov	double		Covariance of e and aop. [stat.covariance]				
e_M_Cov	double		Covariance of e and M. [stat.covariance]				
e_epoch_Cov	double		Covariance of e and epoch. [stat.covariance]				
i_lan_Cov	double		Covariance of i and lan. [stat.covariance]				
i_aop_Cov	double		Covariance of i and aop. [stat.covariance]				
i_M_Cov	double		Covariance of i and M. [stat.covariance]				
i_epoch_Cov	double		Covariance of i and epoch. [stat.covariance]				
lan_aop_Cov	double		Covariance of lan and aop. [stat.covariance]				
lan_M_Cov	double		Covariance of lan and M. [stat.covariance]				
lan_epoch_Cov	double		Covariance of lan and epoch. [stat.covariance]				
aop_M_Cov	double		Covariance of aop and M. [stat.covariance]				
aop_epoch_Cov	double		Covariance of aop and epoch. [stat.covariance]				
M_epoch_Cov	double		Covariance of M and epoch. [stat.covariance]				
arc	float	days	Arc of observation.				
orbFitLnL	float		Natural log of the likelihood of the orbital ele-				
			ments fit. [stat.likelihood]				
orbFitChi2	float		Chi ² statistic of the orbital elements fit.				
			[stat.fit.chi2]				
orbFitNdata	int		Number of observations used in the fit.				
MOID1	float	AU	Minimum orbit intersection distance.				
MOID2	float	AU	Minimum orbit intersection distance.				
moidLon1	double	deg	MOID longitudes.				
moidLon2	double	deg	MOID longitudes.				

Table 3: SSObject Table



LDM-153

Column Name	Data type	Unit	Description [UCD]		
uH	float	mag	Mean absolute magnitude for u filter.		
uHErr	float	mag	Uncertainty of uH estimate. [stat.error]		
uG1	float	mag	Fitted G1 slope parameter for u filter.		
uG1Err	float	mag	Uncertainty of uG1 estimate. [stat.error]		
uG2	float	mag	Fitted G2 slope parameter for u filter.		
uG2Err	float	mag	Uncertainty of uG2 estimate. [stat.error]		
gH	float	mag	Mean absolute magnitude for g filter.		
gHErr	float	mag	Uncertainty of gH estimate. [stat.error]		
gG1	float	mag	Fitted G1 slope parameter for g filter.		
gG1Err	float	mag	Uncertainty of gG1 estimate. [stat.error]		
gG2	float	mag	Fitted G2 slope parameter for g filter.		
gG2Err	float	mag	Uncertainty of gG2 estimate. [stat.error]		
rH	float	mag	Mean absolute magnitude for r filter.		
rHErr	float	mag	Uncertainty of rH estimate. [stat.error]		
rG1	float	mag	Fitted G1 slope parameter for r filter.		
rG1Err	float	mag	Uncertainty of rG1 estimate. [stat.error]		
rG2	float	mag	Fitted G2 slope parameter for r filter.		
rG2Err	float	mag	Uncertainty of rG2 estimate. [stat.error]		
iH	float	mag	Mean absolute magnitude for i filter.		
iHErr	float	mag	Uncertainty of iH estimate. [stat.error]		
iG1	float	mag	Fitted G1 slope parameter for i filter.		
iG1Err	float	mag	Uncertainty of iG1 estimate. [stat.error]		
iG2	float	mag	Fitted G2 slope parameter for i filter.		
iG2Err	float	mag	Uncertainty of iG2 estimate. [stat.error]		
zH	float	mag	Mean absolute magnitude for z filter.		
zHErr	float	mag	Uncertainty of zH estimate. [stat.error]		
zG1	float	mag	Fitted G1 slope parameter for z filter.		
zG1Err	float	mag	Uncertainty of zG1 estimate. [stat.error]		
zG2	float	mag	Fitted G2 slope parameter for z filter.		
zG2Err	float	mag	Uncertainty of zG2 estimate. [stat.error]		
уН	float	mag	Mean absolute magnitude for y filter.		
yHErr	float	mag	Uncertainty of yH estimate. [stat.error]		

Table 3: SSObject Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
yG1	float	mag	Fitted G1 slope parameter for y filter.
yG1Err	float	mag	Uncertainty of yG1 estimate. [stat.error]
yG2	float	mag	Fitted G2 slope parameter for y filter.
yG2Err	float	mag	Uncertainty of yG2 estimate. [stat.error]
flags	long		Flags, bitwise OR tbd. [meta.code]

6.4 DiaSource

Table to store 'difference image sources'; - sources detected at SNR >=5 on difference images.

Column Name	Data type	Unit	Description [UCD]
diaSourceld	long		Unique id. [meta.id; obs.image]
ccdVisitId	long		Id of the ccdVisit where this diaSource was mea- sured. Note that we are allowing a diaSource to belong to multiple amplifiers, but it may not span multiple ccds. [meta.id; obs.image]
diaObjectId	long		Id of the diaObject this source was associated with, if any. If not, it is set to NULL (each diaSource will be associated with either a diaObject or ssObject). [meta.id; src]
ssObjectId	long		Id of the ssObject this source was associated with, if any. If not, it is set to NULL (each diaSource will be associated with either a diaObject or ssObject). [meta.id; src]
parentDiaSourceld	long		Id of the parent diaSource this diaSource has been deblended from, if any. [meta.id; src]
prv_procOrder	int		Position of this diaSource in the processing order relative to other diaSources within a given diaObjectId or ssObjectId.
ssObjectReassocTim	ne		

Table 4: DiaSource Table



LDM-153

Table 4: DiaSource Table

Column Name	Data type	Unit	Description [UCD]			
	timestamp		Time when this diaSource was reassociated from diaObject to ssObject (if such reassociation hap-			
			pens, otherwise NULL).			
midPointTai	double	d	Effective mid-exposure time for this diaSource [time.epoch]			
ra	double	deg	RA-coordinate of the center of this diaSource. [pos.eq.ra]			
raSigma	float	deg	Uncertainty of ra. [stat.error; pos.eq.ra]			
decl	double	deg	Decl-coordinate of the center of this diaSource. [pos.eq.dec]			
declSigma	float	deg	Uncertainty of decl. [stat.error; pos.eq.dec]			
ra_decl_Cov	float	deg ²	Covariance between ra and decl. [stat.covariance]			
х	float	pixel	x position computed by a centroiding algorithm.			
			[pos.cartesian.x]			
xSigma	float	pixel	Uncertainty of x. [stat.error:pos.cartesian.x]			
у	float	pixel	y position computed by a centroiding algorithm. [pos.cartesian.y]			
ySigma	float	pixel	Uncertainty of y. [stat.error:pos.cartesian.y]			
x_y_Cov	float	pixel ²	Covariance between x and y. [stat.covariance]			
apFlux	float	nmgy	Calibrated aperture flux. Note that this actually measures the difference between the template and the visit image. [phot.count]			
apFluxErr	float	nmgy	Estimated uncertainty of apFlux. [stat.error; phot.count]			
snr	float		The signal-to-noise ratio at which this source was detected in the difference image. [stat.snr]			
psFlux	float	nmgy	Calibrated flux for Point Source model. Note this			
			actually measures the flux difference between the			
poEluvCierza	float	10 100 GL -	template and the visit image. [phot.count]			
psFluxSigma	double	nmgy	Uncertainty of psHux.			
рѕка	aouble	deg	RA-coordinate of centroid for point source model.			
			[pos.eq.ra]			



LDM-153

Column Name	Data type	Unit	Description [UCD]					
psRaSigma	float	deg	Uncertainty of psRa. [stat.error; pos.eq.ra]					
psDecl	double	deg	Decl-coordinate of centroid for point source model. [pos.eq.dec]					
psDeclSigma	float	deg	Uncertainty of psDecl. [stat.error; pos.eq.dec]					
psFlux_psRa_Cov	float	ngmy*deg	Covariance between psFlux and psRa. [stat.covariance]					
psFlux_psDecl_Cov	float	ngmy*deg	Covariance between psFlux and psDecl. [stat.covariance]					
psRa_psDecl_Cov	float	deg ²	Covariance between psRa and psDecl. [stat.covariance]					
psLnL	float		Natural log likelihood of the observed data given the Point Source model. [stat.likelihood]					
psChi2	float		Chi ² statistic of the model fit. [stat.fit.chi2]					
psNdata	int		The number of data points (pixels) used to fit the model.					
trailFlux	float	nmgy	Calibrated flux for a trailed source model. Note this actually measures the flux difference between the template and the visit image.					
trailFluxSigma	float	nmgy	Uncertainty of trailFlux.					
trailRa	double	deg	RA-coordinate of centroid for trailed source model. [pos.eq.ra]					
trailRaSigma	float	deg	Uncertainty of trailRa. [stat.error; pos.eq.ra]					
trailDecl	double	deg	Decl-coordinate of centroid for trailed source model. [pos.eq.dec]					
trailDeclSigma	float	deg	Uncertainty of trailDecl. [stat.error; pos.eq.dec]					
trailLength	float	arcsec	Maximum likelihood fit of trail length.					
trailLengthSigma	float	nmgy	Uncertainty of trailLength.					
trailAngle	float	deg	Maximum likelihood fit of the angle between the meridian through the centroid and the trail direction (bearing).					
trailAngleSigma	float ,	nmgy	Uncertainty of trailAngle.					

Table 4: DiaSource Table



LDM-153

Table 4: DiaSource Table

Column Name	Data type	Unit	Description	[UCD]			
	float		Covariance	of	trailFlux	and	d trailRa.
			[stat.covariar	nce]			
trailFlux_trailDecl_C	ov						
	float		Covariance	of	trailFlux	and	trailDecl.
			[stat.covariar	nce]			
trailFlux_trailLength	_Cov						
	float		Covariance	of	trailFlux	and	trailLength
			[stat.covariar	nce]			
trailFlux_trailAngle_	Cov						
	float		Covariance	of	trailFlux	and	trailAngle
			[stat.covariar	nce]			C
trailRa_trailDecl_Cov	V		_	_			
	float		Covariance	of	trailRa	and	trailDecl.
			lstat.covariar	ncel			
trailRa trailLength (Cov						
	float		Covariance	of	trailRa	and	traill ength.
	nout		Istat covariar	ncel	ci din di	ana	
trailRa trailAngle Co	- NV		[statico farial				
	float		Covariance	of	trailRa	and	trailAngle
	nout		[stat covariar	ncel	trainta	unu	ti uni ingle.
trailDoct traill ongth							
tranbeti_trancerigti	float		Covarianco	of	trailDacl	and	traill angth
	noat				trandetr	anu	traillength.
	Carr		[Stat.Covariar	icej			
trailDeci_trailAngle_			Constitution	- 6	ture il Die el		t
	float		Covariance	of	trailDecl	and	trailAngle.
			[stat.covariar	ncej			
trailLength_trailAng	le_Cov			_			
	float		Covariance	of	trailLength	and	trailAngle
			[stat.covariar	nce]			
trailLnL	float		Natural log likelihood of the observed data giver				d data given
			the trailed source model. [stat.likelihood]				od]
trailChi2	float		Chi ² statistic	of the	model fit. [stat.fit.	chi2]



LDM-153

Column Name	Data type	Unit	Description [UCD]
trailNdata	int		The number of data points (pixels) used to fit the model.
dipMeanFlux	float	nmgy	Maximum likelihood value for the mean absolute flux of the two lobes for a dipole model.
dipMeanFluxSigma	float	nmgy	Uncertainty of dipMeanFlux. [stat.error]
dipFluxDiff	float	nmgy	Maximum likelihood value for the difference of ab- solute fluxes of the two lobes for a dipole model.
dipFluxDiffSigma	float	nmgy	Uncertainty of dipFluxDiff. [stat.error]
dipRa	double	deg	RA-coordinate of centroid for dipole model. [pos.eq.ra]
dipRaSigma	float	deg	Uncertainty of trailRa. [stat.error; pos.eq.ra]
dipDecl	double	deg	Decl-coordinate of centroid for dipole model. [pos.eq.dec]
dipDeclSigma	float	deg	Uncertainty of dipDecl. [stat.error; pos.eq.dec]
dipLength	float	arcsec	Maximum likelihood value for the lobe separation in dipole model. [pos.angDistance]
dipLengthSigma	float	arcsec	Uncertainty of dipLength. [stat.error; pos.angDistance]
dipAngle	float	deg	Maximum likelihood fit of the angle between the meridian through the centroid and the dipole di- rection (bearing, from negative to positive lobe). [pos.posAng]
dipAngleSigma	float	deg	Uncertainty of dipAngle. [stat.error; pos.posAng]
dipMeanFlux_dipFlu	ıxDiff_Cov		
	float		Covariance of dipMeanFlux and dipFluxDiff. [stat.covariance]
dipMeanFlux_dipRa	_Cov		
	float		Covariance of dipMeanFlux and dipRa. [stat.covariance]
dipMeanFlux_dipDe	cl_Cov		
	float		Covariance of dipMeanFlux and dipDecl. [stat.covariance]

Table 4: DiaSource Table



LDM-153

Table 4: DiaSource Table

Column Name	Data type	Unit	Description [UCD]
dipMeanFlux_dipLe	ngth_Cov		
	float		Covariance of dipMeanFlux and dipLength.
			[stat.covariance]
dipMeanFlux_dipAr	ngle_Cov		
	float		Covariance of dipMeanFlux and dipAngle.
			[stat.covariance]
dipFluxDiff_dipRa_C	Cov		
	float		Covariance of dipFluxDiff and dipRa.
			[stat.covariance]
dipFluxDiff_dipDecl	_Cov		
	float		Covariance of dipFluxDiff and dipDecl.
			[stat.covariance]
dipFluxDiff_dipLeng	gth_Cov		
	float		Covariance of dipFluxDiff and dipLength.
	<u> </u>		[stat.covariance]
aipFluxDiff_aipAngi	e_Cov		
	fioat		Covariance of dipFluxDiff and dipAngle.
dipDa dipDad Cav	float		[Stat.covariance]
dipRa_dipLeci_Cov	nual		covariance of dipka and dipbeci. [stat.covariance]
	float		Covariance of dinPa and dinLongth
	nual		[stat covariance]
dinRa dinAngle Co	float		Covariance of dinRa and dinAngle
	indat		[stat covariance]
dinDect dintength	Cov		
	float		Covariance of dipDecl and dipLength
	noue		[stat.covariance]
dipDect dinAngle C	OV		
	float		Covariance of dipDecl and dinAngle.
			[stat.covariance]
dipLength_dipAngle	e_Cov		



LDM-153

Column Name	Data type	Unit	Description [UCD]
	float		Covariance of dipLength and dipAngle.
			[stat.covariance]
dipLnL	float		Natural log likelihood of the observed data given
			the dipole source model. [stat.likelihood]
dipChi2	float		Chi ² statistic of the model fit. [stat.fit.chi2]
dipNdata	int		The number of data points (pixels) used to fit the model.
totFlux	float	nmgy	Calibrated flux for Point Source model measured
			on the visit image centered at the centroid mea-
			sured on the difference image (forced photometry
			flux). [phot.count]
totFluxErr	float	nmgy	Estimated uncertainty of totFlux. [stat.error;
			phot.count]
diffFlux	float	nmgy	Calibrated flux for Point Source model centered
			on radec but measured on the difference of snaps
	CI (comprising this visit.
diffFluxErr	float	nmgy	Estimated uncertainty of diffFlux. [stat.error;
foDlad	float		phot.count
трвква	llogr	ningy/asec-	troid) of the object
fnBkødFrr	float	nmgy/asec ²	Estimated uncertainty of foBkgd
ixx	float	nmgy/asec ²	Adaptive second moment of the source intensity
ixxSigma	float	nmgv*asec ²	Uncertainty of ixx. [stat.error]
ivy	float	nmgy*asec ²	Adaptive second moment of the source intensity.
iyySigma	float	nmgy*asec ²	Uncertainty of ivy. [stat.error]
ixy	float	nmgy*asec ²	Adaptive second moment of the source intensity.
ixySigma	float	nmgy*asec ²	Uncertainty of ixy. [stat.error]
ixx_iyy_Cov	float	nmgy ² *asec ²	Covariance of ixx and iyy.
ixx_ixy_Cov	float	nmgy ² *asec ⁴	Covariance of ixx and ixy.
iyy_ixy_Cov	float	nmgy ² *asec ⁴	Covariance of iyy and ixy.
ixxPSF	float	nmgy*asec ²	Adaptive second moment for the PSF.
iyyPSF	float	nmgy*asec ²	Adaptive second moment for the PSF.

Table 4: DiaSource Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
ixyPSF	float	nmgy*asec ²	Adaptive second moment for the PSF.
extendedness	float		A measure of extendedness, Computed using a combination of available moments and model fluxes or from a likelihood ratio of point/trailed source models (exact algorithm TBD). extendedness = 1 implies a high degree of confidence that the source is extended. extendedness = 0 implies a high degree of confidence that the source is point-like.
spuriousness	float		A measure of spuriousness, computed using in- formation from the source and image character- ization, as well as the information on the Tele- scope and Camera system (e.g., ghost maps, de- fect maps, etc.).
flags	long		Flags, bitwise OR tbd. [meta.code]
htmld20	long		HTM index.

Table 4: DiaSource Table

6.5 DiaForcedSource

Forced-photometry source measurement on an individual difference Exposure based on a Multifit shape model derived from a deep detection.

Table 5: DiaForcedSource Table

Column Name	Data type	Unit	Description [UCD]
diaObjectId	long		[meta.id; src]
ccdVisitId	long		Id of the visit where this forcedSource was mea- sured. Note that we are allowing a forcedSource to belong to multiple amplifiers, but it may not span multiple ccds. [meta.id; obs.image]
psFlux	float	nmgy	Point Source model flux. [phot.count]
psFluxSigma	float	nmgy	Uncertainty of psFlux. [stat.error; phot.count]
			Continued on next nage


LDM-153

Table 5:	DiaFord	edSourc	e Table
----------	---------	---------	---------

Column Name	Data type	Unit	Description [UCD]
Х	float	pixel	x position at which psFlux has been measured.
			[pos.cartesian.x]
у	float	pixel	y position at which psFlux has been measured.
			[pos.cartesian.y]
flags	long		Flags, bitwise OR tbd [meta.code]

6.6 DiaObject_To_Object_Match

The table stores mapping of diaObjects to the nearby objects.

Column Name	Data type	Unit	Description [UCD]
diaObjectId	long		ld of diaObject. [meta.id; src]
objectId	long		ld of a nearby object. [meta.id; src]
dist	float	arcsec	The distance between the diaObject and the ob-
			ject.
InP	float		Natural log of the probability that the observed diaObject is the same as the nearby object.

Table 6: DiaObject_To_Object_Match Table

6.7 Object

The Object table contains descriptions of the multi-epoch static astronomical objects, in particular their astrophysical properties as derived from analysis of the Sources that are associated with them. Note that fast moving objects are kept in the MovingObject tables. Note that less-frequently used columns are stored in a separate table called Object_Extra.

Table 7: Object Table

Column Name	Data type Unit	Description [UCD]
objectld	long	Unique id. [meta.id; src]



LDM-153

Column Name	Data type	Unit	Description [UCD]
parentObjectId	long		Id of the parent object this object has been de-
nny inputId	int		Pointer to pry InputType Indicates which input
prv_mputio	IIIC		was used to produce a given object.
psRa	double	deg	RA-coordinate of the center of the object for the Point Source model at time 'psEpoch'. [pos.eq.ra]
psRaSigma	float	deg	Uncertainty of psRa. [stat.error; pos.eq.ra]
psDecl	double	deg	Decl-coordinate of the center of the object for the Point Source model at time 'psEpoch'. [pos.eq.dec]
psDeclSigma	float	deg	Uncertainty of psDecl. [stat.error; pos.eq.dec]
psMuRa	float	mas/yr	Proper motion (ra) for the Point Source model. [pos.pm]
psMuRaSigma	float	mas/yr	Uncertainty of psMuRa. [stat.error; pos.pm]
psMuDecl	float	mas/yr	Proper motion (decl) for the Point Source model. [pos.pm]
psMuDeclSigma	float	mas/yr	Uncertainty of psMuDecl. [stat.error; pos.pm]
psParallax	float	mas	Stellar parallax. for the Point Source model. [pos.parallax]
psParallaxSigma	float	mas	Uncertainty of psParallax. [stat.error; pos.parallax]
uPsFlux	float	nmgy	Calibrated flux for Point Source model for u filter. [phot.count]
uPsFluxSigma	float	nmgy	Uncertainty of uPsFlux. [stat.error; phot.count]
gPsFlux	float	nmgy	Calibrated flux for Point Source model for g filter. [phot.count]
gPsFluxSigma	float	nmgy	Uncertainty of gPsFlux. [stat.error; phot.count]
rPsFlux	float	nmgy	Calibrated flux for Point Source model for r filter. [phot.count]
rPsFluxSigma	float	nmgy	Uncertainty of rPsFlux. [stat.error; phot.count]
iPsFlux	float	nmgy	Calibrated flux for Point Source model for i filter. [phot.count]
iPsFluxSigma	float	nmgy	Uncertainty of iPsFlux. [stat.error; phot.count]
			Continued on next page

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
zPsFlux	float	nmgy	Calibrated flux for Point Source model for z filter.
			[phot.count]
zPsFluxSigma	float	nmgy	Uncertainty of zPsFlux. [stat.error; phot.count]
yPsFlux	float	nmgy	Calibrated flux for Point Source model for y filter.
			[phot.count]
yPsFluxSigma	float	nmgy	Uncertainty of yPsFlux. [stat.error; phot.count]
psLnL	float		Natural log likelihood of the observed data given the Point Source model.
psChi2	float		Chi ² static of the model fit.
psN	int		The number of data points (pixels) used to fit the model.
uBbdRa	double	deg	RA-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For u filter.
			[pos.eq.ra]
uBdRaSigma	float	deg	Uncertainty of uBdRa. [stat.error; pos.eq.ra]
uBdDecl	double	deg	Decl-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For u filter.
			[pos.eq.dec]
uBdDeclSigma	float	deg	Uncertainty of uBdDecl. [stat.error; pos.eq.dec]
uBdE1	float		Ellipticity for the Bulge+Disk (e1). For u filter. [phys.size.axisRatio]
uBdE1Sigma	float		Uncertainty of uBdE1. [stat.error;
			phys.size.axisRatio]
uBdE2	float		Ellipticity for Bulge+Disk model (e2). For u filter.
			[phys.size.axisRatio]
uBdE2Sigma	float		Uncertainty of uBdE2. [stat.error;
			phys.size.axisRatio]
uBdFluxB	float	nmgy	Integrated flux of the de Vaucouleurs component
			for the Bulge+Disk model. For u filter.
uBdFluxBSigma	float	nmgy	Uncertainty of uBdFluxB.
uBdFluxD	float	nmgy	Integrated flux of the exponential component for
			the Bulge+Disk model. For u filter.

Table 7: Object Table



LDM-153

Latest Revision 2019-06-27

Column Name	Data type	Unit	Description [UCD]
uBdFluxDSigma	float	nmgy	Uncertainty of uBdFluxD.
uBdReB	float	arcsec	Effective radius of the de Vaucouleurs profile com-
			ponent for the Bulge+Disk model. For u filter.
uBdReBSigma	float	arcsec	Uncertainty of uBdReB.
uBdReD	float	arcsec	Effective radius of the exponential profile compo-
			nent for the Bulge+Disk model. For u filter.
uBdReDSigma	float	arcsec	Uncertainty of uBdReD.
uBdLnL	float		Natural log likelihood of the observed data given
			the Bulge+Disk model. For u filter.
uBdChi2	float		Chi ² static of the model fit. For u filter.
uBdN	int		The number of data points (pixels) used to fit the
			model. For u filter.
gBbdRa	double	deg	RA-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For g filter.
			[pos.eq.ra]
gBdRaSigma	float	deg	Uncertainty of gBdRa. [stat.error; pos.eq.ra]
gBdDecl	double	deg	Decl-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For g filter.
			[pos.eq.dec]
gBdDeclSigma	float	deg	Uncertainty of gBdDecl. [stat.error; pos.eq.dec]
gBdE1	float		Ellipticity for the Bulge+Disk (e1). For g filter.
			[phys.size.axisRatio]
gBdE1Sigma	float		Uncertainty of gBdE1. [stat.error;
			phys.size.axisRatio]
gBdE2	float		Ellipticity for Bulge+Disk model (e2). For g filter.
			[phys.size.axisRatio]
gBdE2Sigma	float		Uncertainty of gBdE2. [stat.error;
			phys.size.axisRatio]
gBdFluxB	float	nmgy	Integrated flux of the de Vaucouleurs component
			for the Bulge+Disk model. For g filter.
gBdFluxBSigma	float	nmgy	Uncertainty of gBdFluxB.

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
gBdFluxD	float	nmgy	Integrated flux of the exponential component for
			the Bulge+Disk model. For g filter.
gBdFluxDSigma	float	nmgy	Uncertainty of gBdFluxD.
gBdReB	float	arcsec	Effective radius of the de Vaucouleurs profile com-
			ponent for the Bulge+Disk model. For g filter.
gBdReBSigma	float	arcsec	Uncertainty of gBdReB.
gBdReD	float	arcsec	Effective radius of the exponential profile compo- nent for the Bulge+Disk model. For g filter.
gBdReDSigma	float	arcsec	Uncertainty of gBdReD.
gBdLnL	float		Natural log likelihood of the observed data given
0			the Bulge+Disk model. For g filter.
gBdChi2	float		Chi ² static of the model fit. For g filter.
gBdN	int		The number of data points (pixels) used to fit the
			model. For g filter.
rBbdRa	double	deg	RA-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For r filter.
			[pos.eq.ra]
rBdRaSigma	float	deg	Uncertainty of rBdRa. [stat.error; pos.eq.ra]
rBdDecl	double	deg	Decl-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For r filter.
			[pos.eq.dec]
rBdDeclSigma	float	deg	Uncertainty of rBdDecl. [stat.error; pos.eq.dec]
rBdE1	float		Ellipticity for the Bulge+Disk (e1). For r filter.
			[phys.size.axisRatio]
rBdE1Sigma	float		Uncertainty of rBdE1. [stat.error;
			phys.size.axisRatio]
rBdE2	float		Ellipticity for Bulge+Disk model (e2). For r filter.
			[phys.size.axisRatio]
rBdE2Sigma	float		Uncertainty of rBdE2. [stat.error;
			phys.size.axisRatio]
rBdFluxB	float	nmgy	Integrated flux of the de Vaucouleurs component
			for the Bulge+Disk model. For r filter.

Table 7: Object Table



LDM-153

Latest Revision 2019-06-27

Column Name	Data type	Unit	Description [UCD]
rBdFluxBSigma	float	nmgy	Uncertainty of rBdFluxB.
rBdFluxD	float	nmgy	Integrated flux of the exponential component for
			the Bulge+Disk model. For r filter.
rBdFluxDSigma	float	nmgy	Uncertainty of rBdFluxD.
rBdReB	float	arcsec	Effective radius of the de Vaucouleurs profile com-
			ponent for the Bulge+Disk model. For r filter.
rBdReBSigma	float	arcsec	Uncertainty of rBdReB.
rBdReD	float	arcsec	Effective radius of the exponential profile compo-
			nent for the Bulge+Disk model. For r filter.
rBdReDSigma	float	arcsec	Uncertainty of rBdReD.
rBdLnL	float		Natural log likelihood of the observed data given
			the Bulge+Disk model. For r filter.
rBdChi2	float		Chi ² static of the model fit. For r filter.
rBdN	int		The number of data points (pixels) used to fit the
			model. For r filter.
iBbdRa	double	deg	RA-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For i filter.
			[pos.eq.ra]
iBdRaSigma	float	deg	Uncertainty of iBdRa. [stat.error; pos.eq.ra]
iBdDecl	double	deg	Decl-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For i filter.
			[pos.eq.dec]
iBdDeclSigma	float	deg	Uncertainty of iBdDecl. [stat.error; pos.eq.dec]
iBdE1	float		Ellipticity for the Bulge+Disk (e1). For i filter.
			[phys.size.axisRatio]
iBdE1Sigma	float		Uncertainty of iBdE1. [stat.error;
			phys.size.axisRatio]
iBdE2	float		Ellipticity for Bulge+Disk model (e2). For i filter.
			[phys.size.axisRatio]
iBdE2Sigma	float		Uncertainty of iBdE2. [stat.error;
			phys.size.axisRatio]

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
iBdFluxB	float	nmgy	Integrated flux of the de Vaucouleurs component
			for the Bulge+Disk model. For i filter.
iBdFluxBSigma	float	nmgy	Uncertainty of iBdFluxB.
iBdFluxD	float	nmgy	Integrated flux of the exponential component for
			the Bulge+Disk model. For i filter.
iBdFluxDSigma	float	nmgy	Uncertainty of iBdFluxD.
iBdReB	float	arcsec	Effective radius of the de Vaucouleurs profile com-
			ponent for the Bulge+Disk model. For i filter.
iBdReBSigma	float	arcsec	Uncertainty of iBdReB.
iBdReD	float	arcsec	Effective radius of the exponential profile compo-
			nent for the Bulge+Disk model. For i filter.
iBdReDSigma	float	arcsec	Uncertainty of iBdReD.
iBdLnL	float		Natural log likelihood of the observed data given
			the Bulge+Disk model. For i filter.
iBdChi2	float		Chi ² static of the model fit. For i filter.
iBdN	int		The number of data points (pixels) used to fit the model. For i filter.
zBbdRa	double	deg	RA-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For z filter.
			[pos.eq.ra]
zBdRaSigma	float	deg	Uncertainty of zBdRa. [stat.error; pos.eq.ra]
zBdDecl	double	deg	Decl-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For z filter.
			[pos.eq.dec]
zBdDeclSigma	float	deg	Uncertainty of zBdDecl. [stat.error; pos.eq.dec]
zBdE1	float		Ellipticity for the Bulge+Disk (e1). For z filter.
			[phys.size.axisRatio]
zBdE1Sigma	float		Uncertainty of zBdE1. [stat.error;
			phys.size.axisRatio]
zBdE2	float		Ellipticity for Bulge+Disk model (e2). For z filter.
			[phys.size.axisRatio]

Table 7: Object Table



LDM-153

Latest Revision 2019-06-27

Column Name	Data type	Unit	Description [UCD]
zBdE2Sigma	float		Uncertainty of zBdE2. [stat.error;
			phys.size.axisRatio]
zBdFluxB	float	nmgy	Integrated flux of the de Vaucouleurs component
			for the Bulge+Disk model. For z filter.
zBdFluxBSigma	float	nmgy	Uncertainty of zBdFluxB.
zBdFluxD	float	nmgy	Integrated flux of the exponential component for
			the Bulge+Disk model. For z filter.
zBdFluxDSigma	float	nmgy	Uncertainty of zBdFluxD.
zBdReB	float	arcsec	Effective radius of the de Vaucouleurs profile com-
			ponent for the Bulge+Disk model. For z filter.
zBdReBSigma	float	arcsec	Uncertainty of zBdReB.
zBdReD	float	arcsec	Effective radius of the exponential profile compo-
			nent for the Bulge+Disk model. For z filter.
zBdReDSigma	float	arcsec	Uncertainty of zBdReD.
zBdLnL	float		Natural log likelihood of the observed data given
			the Bulge+Disk model. For z filter.
zBdChi2	float		Chi ² static of the model fit. For z filter.
zBdN	int		The number of data points (pixels) used to fit the
			model. For z filter.
yBbdRa	double	deg	RA-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For y filter.
			[pos.eq.ra]
yBdRaSigma	float	deg	Uncertainty of yBdRa. [stat.error; pos.eq.ra]
yBdDecl	double	deg	Decl-coordinate of the center of the object for the
			Bulge+Disk model at time radecTai. For y filter.
			[pos.eq.dec]
yBdDeclSigma	float	deg	Uncertainty of yBdDecl. [stat.error; pos.eq.dec]
yBdE1	float		Ellipticity for the Bulge+Disk (e1). For y filter.
			[phys.size.axisRatio]
yBdE1Sigma	float		Uncertainty of yBdE1. [stat.error;
			phys.size.axisRatio]

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
yBdE2	float		Ellipticity for Bulge+Disk model (e2). For y filter.
			[phys.size.axisRatio]
yBdE2Sigma	float		Uncertainty of yBdE2. [stat.error;
			phys.size.axisRatio]
yBdFluxB	float	nmgy	Integrated flux of the de Vaucouleurs component
			for the Bulge+Disk model. For y filter.
yBdFluxBSigma	float	nmgy	Uncertainty of yBdFluxB.
yBdFluxD	float	nmgy	Integrated flux of the exponential component for
			the Bulge+Disk model. For y filter.
yBdFluxDSigma	float	nmgy	Uncertainty of yBdFluxD.
yBdReB	float	arcsec	Effective radius of the de Vaucouleurs profile com-
			ponent for the Bulge+Disk model. For y filter.
yBdReBSigma	float	arcsec	Uncertainty of yBdReB.
yBdReD	float	arcsec	Effective radius of the exponential profile compo-
			nent for the Bulge+Disk model. For y filter.
yBdReDSigma	float	arcsec	Uncertainty of yBdReD.
yBdLnL	float		Natural log likelihood of the observed data given
			the Bulge+Disk model. For y filter.
yBdChi2	float		Chi ² static of the model fit. For y filter.
yBdN	int		The number of data points (pixels) used to fit the
			model. For y filter.
ugStd	float	mag	Color of the object measured in 'standard seeing'.
			While the exact algorithm is yet to be determined,
			this color is guaranteed to be seeing-independent
			and suitable for photo-Z determinations.
ugStdSigma	float	mag	Uncertainty of ugStd.
grStd	float	mag	Color of the object measured in 'standard seeing'.
			While the exact algorithm is yet to be determined,
			this color is guaranteed to be seeing-independent
			and suitable for photo-Z determinations.
grStdSigma	float	mag	Uncertainty of grStd.

Table 7: Object Table



LDM-153

Table 7: Object Table

Column Name	Data type	Unit	Description [UCD]
riStd	float	mag	Color of the object measured in 'standard see- ing'. While the exact algorithm is yet to be de- termined, this color is is guaranteed to be seeing- independent and suitable for photo-Z determina- tions.
riStdSigma	float	mag	Uncertainty of riStd.
izStd	float	mag	Color of the object measured in 'standard seeing'. While the exact algorithm is yet to be determined, this color is guaranteed to be seeing-independent and suitable for photo-Z determinations.
izStdSigma	float	mag	Uncertainty of izStd.
zyStd	float	mag	Color of the object measured in 'standard seeing'. While the exact algorithm is yet to be determined, this color is guaranteed to be seeing-independent and suitable for photo-Z determinations.
zyStdSigma	float	mag	Uncertainty of zyStd.
uRa	double	arcsec	RA-coordinate coordinate of the centroid com- puted for u filter. [pos.eq.ra]
uRaSigma	double	arcsec	Uncertainty of uRa. [stat.error; pos.eq.ra]
uDecl	double	arcsec	Decl-coordinate coordinate of the centroid com- puted for u filter. [pos.eq.dec]
uDeclSigma	double	arcsec	Uncertainty of uDecl. [stat.error; pos.eq.dec]
gRa	double	arcsec	RA-coordinate coordinate of the centroid com- puted for g filter. [pos.eq.ra]
gRaSigma	double	arcsec	Uncertainty of gRa. [stat.error; pos.eq.ra]
gDecl	double	arcsec	Decl-coordinate coordinate of the centroid com- puted for g filter. [pos.eq.dec]
gDeclSigma	double	arcsec	Uncertainty of gDecl. [stat.error; pos.eq.dec]
rRa	double	arcsec	RA-coordinate coordinate of the centroid com- puted for r filter. [pos.eq.ra]
rRaSigma	double	arcsec	Uncertainty of rRa. [stat.error; pos.eq.ra]



LDM-153

Column Name	Data type	Unit	Description [UCD]
rDecl	double	arcsec	Decl-coordinate coordinate of the centroid com-
			puted for r filter. [pos.eq.dec]
rDeclSigma	double	arcsec	Uncertainty of rDecl. [stat.error; pos.eq.dec]
iRa	double	arcsec	RA-coordinate coordinate of the centroid com-
			puted for i filter. [pos.eq.ra]
iRaSigma	double	arcsec	Uncertainty of iRa. [stat.error; pos.eq.ra]
iDecl	double	arcsec	Decl-coordinate coordinate of the centroid com-
			puted for i filter. [pos.eq.dec]
iDeclSigma	double	arcsec	Uncertainty of iDecl. [stat.error; pos.eq.dec]
zRa	double	arcsec	RA-coordinate coordinate of the centroid com-
			puted for z filter. [pos.eq.ra]
zRaSigma	double	arcsec	Uncertainty of zRa. [stat.error; pos.eq.ra]
zDecl	double	arcsec	Decl-coordinate coordinate of the centroid com-
			puted for z filter. [pos.eq.dec]
zDeclSigma	double	arcsec	Uncertainty of zDecl. [stat.error; pos.eq.dec]
yRa	double	arcsec	RA-coordinate coordinate of the centroid com-
			puted for y filter. [pos.eq.ra]
yRaSigma	double	arcsec	Uncertainty of yRa. [stat.error; pos.eq.ra]
yDecl	double	arcsec	Decl-coordinate coordinate of the centroid com-
			puted for y filter. [pos.eq.dec]
yDeclSigma	double	arcsec	Uncertainty of yDecl. [stat.error; pos.eq.dec]
uE1	float		Adaptive e1 shape measure for u filter. See
			Bernstein and Jarvis (2002) for detailed discus-
			sion of all adaptive-moment related quantities.
			[phys.size.axisRatio]
uE1Sigma	float		Uncertainty of uE1 [stat.error; phys.size.axisRatio]
uE2	float		Adaptive e2 shape measure for u filter. See
			Bernstein and Jarvis (2002) for detailed discus-
			sion of all adaptive-moment related quantities.
			[phys.size.axisRatio]
uE2Sigma	float		Uncertainty of uE2 [stat.error; phys.size.axisRatio]
uE1_E2_Cov	float		Covariance of uE1 and uE2.

Table 7: Object Table



LDM-153

Table 7: Object Table

Column Name	Data type	Unit	Description [UCD]
gE1	float		Adaptive e1 shape measure for g filter. See Bernstein and Jarvis (2002) for detailed discus- sion of all adaptive-moment related quantities. [phys.size.axisRatio]
gE1Sigma	float		Uncertainty of gE1 [stat.error; phys.size.axisRatio]
gE2	float		Adaptive e2 shape measure for g filter. See Bernstein and Jarvis (2002) for detailed discus- sion of all adaptive-moment related quantities. [phys.size.axisRatio]
gE2Sigma	float		Uncertainty of gE2 [stat.error; phys.size.axisRatio]
gE1_E2_Cov	float		Covariance of gE1 and gE2.
rE1	float		Adaptive e1 shape measure for r filter. See Bernstein and Jarvis (2002) for detailed discus- sion of all adaptive-moment related quantities. [phys.size.axisRatio]
rE1Sigma	float		Uncertainty of rE1 [stat.error; phys.size.axisRatio]
rE2	float		Adaptive e2 shape measure for r filter. See Bernstein and Jarvis (2002) for detailed discus- sion of all adaptive-moment related quantities. [phys.size.axisRatio]
rE2Sigma	float		Uncertainty of rE2 [stat.error; phys.size.axisRatio]
rE1_E2_Cov	float		Covariance of rE1 and rE2.
iE1	float		Adaptive e1 shape measure for i filter. See Bernstein and Jarvis (2002) for detailed discus- sion of all adaptive-moment related quantities. [phys.size.axisRatio]
iE1Sigma	float		Uncertainty of iE1 [stat.error; phys.size.axisRatio]
iE2	float		Adaptive e2 shape measure for i filter. See Bernstein and Jarvis (2002) for detailed discus- sion of all adaptive-moment related quantities. [phys.size.axisRatio]
iE2Sigma	float		Uncertainty of iE2 [stat.error; phys.size.axisRatio]
			Continued on next page



LDM-153

Column Name	Data type Unit	Description [UCD]
iE1_E2_Cov	float	Covariance of iE1 and iE2.
zE1	float	Adaptive e1 shape measure for z filter. See
		Bernstein and Jarvis (2002) for detailed discus-
		sion of all adaptive-moment related quantities.
		[phys.size.axisRatio]
zE1Sigma	float	Uncertainty of zE1 [stat.error; phys.size.axisRatio]
zE2	float	Adaptive e2 shape measure for z filter. See
		Bernstein and Jarvis (2002) for detailed discus-
		sion of all adaptive-moment related quantities.
		[phys.size.axisRatio]
zE2Sigma	float	Uncertainty of zE2 [stat.error; phys.size.axisRatio]
zE1_E2_Cov	float	Covariance of zE1 and zE2.
yE1	float	Adaptive e1 shape measure for y filter. See
		Bernstein and Jarvis (2002) for detailed discus-
		sion of all adaptive-moment related quantities.
		[phys.size.axisRatio]
yE1Sigma	float	Uncertainty of yE1 [stat.error; phys.size.axisRatio]
yE2	float	Adaptive e2 shape measure for y filter. See
		Bernstein and Jarvis (2002) for detailed discus-
		sion of all adaptive-moment related quantities.
		[phys.size.axisRatio]
yE2Sigma	float	Uncertainty of yE2 [stat.error; phys.size.axisRatio]
yE1_E2_Cov	float	Covariance of yE1 and yE2.
uMSum	float	Sum of second adaptive moments for u filter.
uMSumSigma	float	Uncertainty of uMSum
gMSum	float	Sum of second adaptive moments for g filter.
gMSumSigma	float	Uncertainty of gMSum
rMSum	float	Sum of second adaptive moments for r filter.
rMSumSigma	float	Uncertainty of rMSum
iMSum	float	Sum of second adaptive moments for i filter.
iMSumSigma	float	Uncertainty of iMSum
zMSum	float	Sum of second adaptive moments for z filter.

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
zMSumSigma	float		Uncertainty of zMSum
yMSum	float		Sum of second adaptive moments for y filter.
yMSumSigma	float		Uncertainty of yMSum
uM4	float		Fourth order adaptive moment for u filter.
gM4	float		Fourth order adaptive moment for g filter.
rM4	float		Fourth order adaptive moment for r filter.
iM4	float		Fourth order adaptive moment for i filter.
zM4	float		Fourth order adaptive moment for z filter.
yM4	float		Fourth order adaptive moment for y filter.
uPetroRad	float	arcsec	Petrosian radius, computed using elliptical aper-
			tures defined by the adaptive moments for u filter.
uPetroRadSigma	float	arcsec	Uncertainty of uPetroRad
gPetroRad	float	arcsec	Petrosian radius, computed using elliptical aper-
			tures defined by the adaptive moments for g filter.
gPetroRadSigma	float	arcsec	Uncertainty of gPetroRad
rPetroRad	float	arcsec	Petrosian radius, computed using elliptical aper-
			tures defined by the adaptive moments for r filter.
rPetroRadSigma	float	arcsec	Uncertainty of rPetroRad
iPetroRad	float	arcsec	Petrosian radius, computed using elliptical aper-
			tures defined by the adaptive moments for i filter.
iPetroRadSigma	float	arcsec	Uncertainty of iPetroRad
zPetroRad	float	arcsec	Petrosian radius, computed using elliptical aper-
			tures defined by the adaptive moments for z filter.
zPetroRadSigma	float	arcsec	Uncertainty of zPetroRad
yPetroRad	float	arcsec	Petrosian radius, computed using elliptical aper-
			tures defined by the adaptive moments for y filter.
yPetroRadSigma	float	arcsec	Uncertainty of yPetroRad
petroFilter	char		Name of the filter of the canonical petroRad.
uPetroFlux	float	nmgy	Petrosian flux within a defined multiple of the
			canonical petroRad for u filter.
uPetroFluxSigma	float	nmgy	Uncertainty of uPetroFlux.

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
gPetroFlux	float	nmgy	Petrosian flux within a defined multiple of the
			canonical petroRad for g filter.
gPetroFluxSigma	float	nmgy	Uncertainty of gPetroFlux.
rPetroFlux	float	nmgy	Petrosian flux within a defined multiple of the
			canonical petroRad for r filter.
rPetroFluxSigma	float	nmgy	Uncertainty of rPetroFlux.
iPetroFlux	float	nmgy	Petrosian flux within a defined multiple of the
			canonical petroRad for i filter.
iPetroFluxSigma	float	nmgy	Uncertainty of iPetroFlux.
zPetroFlux	float	nmgy	Petrosian flux within a defined multiple of the
			canonical petroRad for z filter.
zPetroFluxSigma	float	nmgy	Uncertainty of zPetroFlux.
yPetroFlux	float	nmgy	Petrosian flux within a defined multiple of the
			canonical petroRad for y filter.
yPetroFluxSigma	float	nmgy	Uncertainty of yPetroFlux.
uPetroRad50	float	arcsec	Radius containing 50% of Petrosian flux for u filter.
uPetroRad50Sigma	float	arcsec	Uncertainty of uPetroRad50.
gPetroRad50	float	arcsec	Radius containing 50% of Petrosian flux for g filter.
gPetroRad50Sigma	float	arcsec	Uncertainty of gPetroRad50.
rPetroRad50	float	arcsec	Radius containing 50% of Petrosian flux for r filter.
rPetroRad50Sigma	float	arcsec	Uncertainty of rPetroRad50.
iPetroRad50	float	arcsec	Radius containing 50% of Petrosian flux for i filter.
iPetroRad50Sigma	float	arcsec	Uncertainty of iPetroRad50.
zPetroRad50	float	arcsec	Radius containing 50% of Petrosian flux for z filter.
zPetroRad50Sigma	float	arcsec	Uncertainty of zPetroRad50.
yPetroRad50	float	arcsec	Radius containing 50% of Petrosian flux for y filter.
yPetroRad50Sigma	float	arcsec	Uncertainty of yPetroRad50.
uPetroRad90	float	arcsec	Radius containing 90% of Petrosian flux for u filter.
uPetroRad90Sigma	float	arcsec	Uncertainty of uPetroRad90.
gPetroRad90	float	arcsec	Radius containing 90% of Petrosian flux for g filter.
gPetroRad90Sigma	float	arcsec	Uncertainty of gPetroRad90.
rPetroRad90	float	arcsec	Radius containing 90% of Petrosian flux for r filter.

Table 7: Object Table



LDM-153

Latest Revision 2019-06-27

Column Name	Data type	Unit	Description [UCD]
rPetroRad90Sigma	float	arcsec	Uncertainty of rPetroRad90.
iPetroRad90	float	arcsec	Radius containing 90% of Petrosian flux for i filter.
iPetroRad90Sigma	float	arcsec	Uncertainty of iPetroRad90.
zPetroRad90	float	arcsec	Radius containing 90% of Petrosian flux for z filter.
zPetroRad90Sigma	float	arcsec	Uncertainty of zPetroRad90.
yPetroRad90	float	arcsec	Radius containing 90% of Petrosian flux for y filter.
yPetroRad90Sigma	float	arcsec	Uncertainty of yPetroRad90.
uKronRad	float	arcsec	Kron radius (computed using elliptical apertures
			defined by the adaptive moments) for u filter.
uKronRadSigma	float	arcsec	Uncertainty of uKronRad.
gKronRad	float	arcsec	Kron radius (computed using elliptical apertures
			defined by the adaptive moments) for g filter.
gKronRadSigma	float	arcsec	Uncertainty of gKronRad.
rKronRad	float	arcsec	Kron radius (computed using elliptical apertures
			defined by the adaptive moments) for r filter.
rKronRadSigma	float	arcsec	Uncertainty of rKronRad.
iKronRad	float	arcsec	Kron radius (computed using elliptical apertures
			defined by the adaptive moments) for i filter.
iKronRadSigma	float	arcsec	Uncertainty of iKronRad.
zKronRad	float	arcsec	Kron radius (computed using elliptical apertures
			defined by the adaptive moments) for z filter.
zKronRadSigma	float	arcsec	Uncertainty of zKronRad.
yKronRad	float	arcsec	Kron radius (computed using elliptical apertures
			defined by the adaptive moments) for y filter.
yKronRadSigma	float	arcsec	Uncertainty of yKronRad.
kronFilter	char		The filter of the canonical kronRad.
uKronFlux	float	nmgy	Kron flux within a defined multiple of the canonical
			kronRad for u filter.
uKronFluxSigma	float	nmgy	Uncertainty of uKronFlux.
gKronFlux	float	nmgy	Kron flux within a defined multiple of the canonical
			kronRad for g filter.
gKronFluxSigma	float	nmgy	Uncertainty of gKronFlux.

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
rKronFlux	float	nmgy	Kron flux within a defined multiple of the canonical
			kronRad for r filter.
rKronFluxSigma	float	nmgy	Uncertainty of rKronFlux.
iKronFlux	float	nmgy	Kron flux within a defined multiple of the canonical
			kronRad for i filter.
iKronFluxSigma	float	nmgy	Uncertainty of iKronFlux.
zKronFlux	float	nmgy	Kron flux within a defined multiple of the canonical
			kronRad for z filter.
zKronFluxSigma	float	nmgy	Uncertainty of zKronFlux.
yKronFlux	float	nmgy	Kron flux within a defined multiple of the canonical
			kronRad for y filter.
yKronFluxSigma	float	nmgy	Uncertainty of yKronFlux.
uKronRad50	float	arcsec	Radius containing 50% of Kron flux for u filter.
uKronRad50Sigma	float	arcsec	Uncertainty of uKronRad50.
gKronRad50	float	arcsec	Radius containing 50% of Kron flux for g filter.
gKronRad50Sigma	float	arcsec	Uncertainty of gKronRad50.
rKronRad50	float	arcsec	Radius containing 50% of Kron flux for r filter.
rKronRad50Sigma	float	arcsec	Uncertainty of rKronRad50.
iKronRad50	float	arcsec	Radius containing 50% of Kron flux for i filter.
iKronRad50Sigma	float	arcsec	Uncertainty of iKronRad50.
zKronRad50	float	arcsec	Radius containing 50% of Kron flux for z filter.
zKronRad50Sigma	float	arcsec	Uncertainty of zKronRad50.
yKronRad50	float	arcsec	Radius containing 50% of Kron flux for y filter.
yKronRad50Sigma	float	arcsec	Uncertainty of yKronRad50.
uKronRad90	float	arcsec	Radius containing 90% of Kron flux for u filter.
uKronRad90Sigma	float	arcsec	Uncertainty of uKronRad90.
gKronRad90	float	arcsec	Radius containing 90% of Kron flux for g filter.
gKronRad90Sigma	float	arcsec	Uncertainty of gKronRad90.
rKronRad90	float	arcsec	Radius containing 90% of Kron flux for r filter.
rKronRad90Sigma	float	arcsec	Uncertainty of rKronRad90.
iKronRad90	float	arcsec	Radius containing 90% of Kron flux for i filter.
iKronRad90Sigma	float	arcsec	Uncertainty of iKronRad90.

Table 7: Object Table



LDM-153

Column Name	Data type	Unit	Description [UCD]
zKronRad90	float	arcsec	Radius containing 90% of Kron flux for z filter.
zKronRad90Sigma	float	arcsec	Uncertainty of zKronRad90.
yKronRad90	float	arcsec	Radius containing 90% of Kron flux for y filter.
yKronRad90Sigma	float	arcsec	Uncertainty of yKronRad90.
uApN	byte		Number of elliptical annuli (see below) for u filter.
gApN	byte		Number of elliptical annuli (see below) for g filter.
rApN	byte		Number of elliptical annuli (see below) for r filter.
iApN	byte		Number of elliptical annuli (see below) for i filter.
zApN	byte		Number of elliptical annuli (see below) for z filter.
уАрN	byte		Number of elliptical annuli (see below) for y filter.
extendedness	float		A measure of extendedness, computed using a
			combination of available moments and model
			fluxes or from a likelihood ratio of point/trailed
			source models (exact algorithm TBD). extended-
			ness = 1 implies a high degree of confidence that
			the source is extended. extendedness = 0 im-
			plies a high degree of confidence that the source
			is point-like.
FLAGS1	long		Flags, tbd.
FLAGS2	long		Flags, tbd.

Table 7: Object Table

6.8 Object_Extra

Less frequently used information from The Object table.

Table 8: Ob	ject_Extra	Table
-------------	------------	-------

Column Name	Data type Unit	Description [UCD]
objectId	long	Unique id. [meta.id; src]
psCov	binary	Various covariances for Point Source model. 66 TINYINTs.
bdCov	binary	Covariance matrix for the Bulge+Disk model. 168 TINYINTs. [((8x9/2)-8)*6].
		Continued on next page

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Column Name	Data type	Unit	Description [UCD]
bdSamples	binary		Independent samples of Bulge+Disk likelihood
			surface. All sampled quantities will be stored with
			at lease 3 significant digits of precision. The num-
			ber of samples will vary from object to object, de-
			pending on how well the object's likelihood func-
			tion is approximated by a Gaussian. We are as-
			suming on average [9x200x4 FLOAT16].
photoZ	photoZ binary	Photometric redshift likelihood samples (pairs of	
			z, logL) computed using a to-be-determined pub-
			lished and widely accepted algorithm at the time
			of LSST Commissioning. [2x100 FLOAT].

Table 8: Object_Extra Table

6.9 Object_APMean

Aperture mean (per bin) for the Object table. We expect 8 bins on average per object.

Column Name	Data type	Unit	Description [UCD]
objectId	long		Unique id. [meta.id; src]
filterName	char		Name of the filter.
binN	byte		A bin in radius at which the aperture measurement
			is being performed.
sbMean	float	nmgy/arcsec	Mean surface brightness at which the aperture
			measurement is being performed.
sbSigma	float		Standard deviation of pixel surface brightness in
			annulus.

6.10 Object_Periodic

Definition of periodic features for Object table. We expect about 32 per object.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Table 10: Object_Periodic Table

Column Name	Data type Unit	Description [UCD]
objectId	long	Unique id. [meta.id; src]
filterName	char	Name of the filter.
theFeature	byte	Feature/metric identifier.
theValue	float	Feature/metric value.

6.11 Object_NonPeriodic

Definition of non-periodic features for Object table. We expect about 20 per object.

Table 11:	Object_	NonPeriodic	Table

Column Name	Data type Unit	Description [UCD]
objectId	long	Unique id. [meta.id; src]
filterName	char	Name of the filter.
theFeature	byte	Feature/metric identifier.
theValue	float	Feature/metric value.

6.12 Source

Table to store high signal-to-noise "sources". A source is a measurement of Object's properties from a single image that contains its footprint on the sky.

Table 12: Source Table

Column Name	Data type Unit	Description [UCD]
sourceld	long	Unique id. [meta.id; src]
ccdVisitId	long	Id of the ccdVisit where this source was measured.
		Note that we are allowing a source to belong to
		multiple amplifiers, but it may not span multiple
		ccds. [meta.id; obs.image]



LDM-153

Table 12: Source Table

Column Name	Data type	Unit	Description [UCD]
filterName	char		Name of the filter used to take the two exposures
			where this source was measured. [meta.id; in-
			str.filter]
objectld	long		Id of the corresponding object. Note that this
			might be NULL (each source will point to either ob-
			ject or ssObject). [meta.id; src]
ssObjectId	long		Id of the corresponding ssObject. Note that this
			might be NULL (each source will point to either ob-
			ject or ssObject). [meta.id; src]
parentSourceld	long		Id of the parent source this source has been de-
			blended from, if any.
htmld20	long		HTM index.
sky	float	nmgy/asec ²	Estimated sky background at the position (cen-
		-	troid) of the source.
skySigma	float	nmgy/asec ²	Uncertainty of sky.
psFlux	float	nmgy	Calibrated flux for Point Source model.
			[phot.count]
psFluxSigma	float	nmgy	Uncertainty of psFlux.
psX	float	pixels	Point source model (x) position of the object on the
	CI		CCD.
psXSigma	float	pixels	Uncertainty of psX.
psY	float		Point source model (y) position of the object on the
	ci .		CCD.
psYSigma	float	pixels	Uncertainty of psy.
psFlux_psX_Cov	float		Covariance of psFlux and psX.
psFlux_psY_Cov	float		Covariance of psFlux and psY.
psX_Y_Cov	float		Covariance of psX and psY.
psLnL	float		Natural log likelihood of the observed data given
	a .		the Point Source model.
psChi2	TIOAt		Chir static of the model fit.
psiv	int		ine number of data points (pixels) used to fit the
			model.



LDM-153

Column Name	Data type	Unit	Description [UCD]	
psRa	double	deg	RA-coordinate of the center of the object for the	
			Point Source model at time radecTai. [pos.eq.ra]	
psRaSigma	float	deg	Uncertainty of psRa. [stat.error; pos.eq.ra]	
psDecl	double	deg	Decl-coordinate of the center of the object for the	
			Point Source model at time radecTai. [pos.eq.dec]	
psDeclSigma	float	deg	Uncertainty of psDecl. [stat.error; pos.eq.dec]	
psFlux_psRa_Cov	float		Covariance of psFlux and psRa.	
psFlux_psDecl_Cov	float		Covariance of psFlux and psRa.	
Х	float	pixel	x position computed using an algorithm similar to	
			that used by SDSS. [pos.cartesian.x]	
xSigma	float	pixel	Uncertainty of x. [stat.error:pos.cartesian.x]	
У	float	pixel	y position computed using an algorithm similar to	
			that used by SDSS. [pos.cartesian.y]	
ySigma	float	pixel	Uncertainty of y. [stat.error:pos.cartesian.y]	
x_y_Cov	float	pixel ²	Covariance between x and y.	
ra	double	arcsec	Calibrated RA-coordinate of the center of the	
			source transformed from xy. [pos.eq.ra]	
raSigma	float	arcsec	Uncertainty of ra. [stat.error; pos.eq.ra]	
decl	double	arcsec	Calibated Decl-coordinate of the center of the	
			source transformed from xy. [pos.eq.dec]	
declSigma	float	arcsec	Uncertainty of decl. [stat.error; pos.eq.dec]	
ra_decl_Cov	float	arcsec ²	Covariance of ra and decl.	
E1	float		Adaptive e1 shape measure of the source	
			as measured on the difference image.	
			[phys.size.axisRatio]	
E1Sigma	float		Uncertainty of E1. [stat.error:phys.size.axisRatio]	
E2	float		Adaptive e2 shape measure of the source	
			as measured on the difference image.	
			[phys.size.axisRatio]	
E2Sigma	float		Uncertainty of E2. [stat.error:phys.size.axisRatio]	
E1_E2_Cov	float		Covariance of E1 and E2	
mSum	float		Sum of second adaptive moments.	

Table 12: Source Table



LDM-153

Table 12: Source Table

Column Name	Data type Unit	Description [UCD]
mSumSigma	float	Uncertainty of mSum.
m4	float	Fourth order adaptive moment.
apN	byte	Number of elliptical annuli.
flags	long	Flags. Tbd.

6.13 Source_APMean

Aperture mean (per bin) for the Source table. We expect 8 bins on average per source.

Table 13: Source_APMean Table

Column Name	Data type	Unit	Description [UCD]
sourceld	long		Unique id. [meta.id; src]
binN	byte		A bin in radius at which the aperture measurement
			is being performed.
sbMean	float	nmgy/arcsec	Mean surface brightness at which the aperture
			measurement is being performed.
sbSigma	float		Standard deviation of pixel surface brightness in
			annulus.

6.14 ForcedSource

Forced-photometry source measurement on an individual Exposure based on a Multifit shape model derived from a deep detection.

Table 14:	ForcedSource	Table
-----------	--------------	-------

Column Name	Data type	Unit	Description [UCD]
objectId	long		[meta.id; src]
ccdVisitId	long		Id of the ccd visit where this forcedSource was
			measured. Note that we are allowing a forced-
			Source to belong to multiple amplifiers, but it may
			not span multiple ccds. [meta.id; obs.image]
			Continued on next page



LDM-153

Table 14: ForcedSource Table

Column Name	Data type	Unit	Description [UCD]	
psFlux	float	nmgy	Point Source model flux. [phot.count]	
psFlux_Sigma	float	nmgy	Uncertainty of psFlux. [stat.error; phot.count]	
flags	byte		Flags, bitwise OR tbd [meta.code]	

6.15 RawAmpExposure

Exposure for one amplifier (raw image).

Tabl	e 15:	RawAmpExposure ⁻	Table
------	-------	-----------------------------	-------

Column Name	Data type	Unit	Description [UCD]				
rawAmpExposureId	long		Primary key (unique identifier). [meta.id;				
			obs.image]				
rawCcdExposureId	long		Pointer to RawCcdExposure containing this amp				
			exposure. [meta.id; obs.image]				
ampName	char	har Amplifier name. [meta.id; instr.det]					
ccdName	char		Ccd name. [meta.id; instr.det]				
raftName	char		Raft name. [meta.id; instr.det]				
filterName	char		Filter name. [meta.id; instr.filter]				
ra	double	deg	Ra of amp center. [pos.eq.ra]				
decl	double	deg	Decl of amp center. [pos.eq.dec]				
skyRotation	double	deg	Sky rotation angle.				
bias	float	DN	Bias as measured from overscan columns.				
biasNom	float	DN	Preset bias.				
gain	float	electrons/DN	N Measured gain value.				
gainNom	float	DN	Preset gain.				
rdNoise	float	DN	Read noise for detector/amplifier.				
saturation	int	DN	Maximum data value for A/D converter.				
llcx	int	pixels	FITS pixel coordinates (0.5, 0.5).				
llcy	int	pixels	FITS pixel coordinates (0.5, 0.5).				
ulcx	int	pixels	FITS pixel coordinates (0.5, 0.5+NAXIS2).				
ulcy	int	pixels	FITS pixel coordinates (0.5, 0.5+NAXIS2).				
urcx	int	pixels	FITS pixel coordinates (0.5+NAXIS1, 0.5+NAXIS2).				
			Continued on next page				

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Column Name	Data type	Unit	Description [UCD]			
urcy	int	pixels	FITS pixel coordinates (0.5+NAXIS1, 0.5+NAXIS2).			
lrcx	int	pixels	FITS pixel coordinates (0.5+NAXIS1, 0.5).			
lrcy	int	pixels	FITS pixel coordinates (0.5+NAXIS1, 0.5).			
xSize	int		Number of columns in the image.			
ySize	int		Number of rows in the image.			
obsStart	timestamp		Start of the exposure, TAI, accurate to 10ms.			
			[time.start]			
expMidpt	double		Midpoint for exposure. TAI, accurate to 10ms.			
			[time.epoch]			
expTime	double	S	Duration of exposure, accurate to 10ms.			
			[time.duration]			
darkTime	double	S	Dark current accumulation time, accurate to			
			10ms. [time.duration]			
flags	int		[meta.code]			

Table 15: RawAmpExposure Table

6.16 RawAmpExposureMetadata

Generic key-value pair metadata for RawAmpExposure.

Table 16:	RawAmpExposureMetadata Table
-----------	------------------------------

Column Name	Data type Unit	Description [UCD]
rawAmpExposureId	long	Id of the corresponding RawAmpExposure.
		[meta.id; obs.image]
metadataKey	string	
intValue	int	
doubleValue	double	
stringValue	string	

6.17 RawCcdExposure

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Column Name	Data type	Unit	Description [UCD]				
rawCcdExposureId	long		Primary key (unique identifier). [meta.id;				
			obs.image]				
rawExposureId	long		Point to the RawExposure containing this ccd ex-				
			posure. [meta.id; obs.image]				
ccdName	char		Ccd name. [meta.id; instr.det]				
raftName	char		Raft name. [meta.id; instr.det]				
filterName	char		Filter name. [meta.id; instr.filter]				
ra	double	deg	RA of field of view center. [pos.eq.ra]				
decl	double	deg	Declination of field of view center. [pos.eq.dec]				
skyRotation	double	deg	Sky rotation angle.				
zenithDistance	float	deg	Zenith distance at observation mid-point.				
			[pos.az.zd]				
airmass	float		Airmass at the observed line of sight.				
llcx	int	pixels	FITS pixel coordinates (0.5, 0.5).				
llcy	int	pixels	FITS pixel coordinates (0.5, 0.5).				
ulcx	int	pixels	FITS pixel coordinates (0.5, 0.5+ySize).				
ulcy	int	pixels	FITS pixel coordinates (0.5, 0.5+ySize).				
urcx	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5+ySize).				
urcy	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5+ySize).				
lrcx	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5).				
lrcy	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5).				
xSize	int		Number of rows in the image.				
ySize	int		Number of columns in the image.				
obsStart	timestamp		Start of the exposure, TAI, accurate to 10ms.				
			[time.start]				
expMidpt	double		Midpoint for exposure. TAI, accurate to 10ms.				
			[time.epoch]				
expTime	double	S	Duration of exposure, accurate to 10ms.				
			[time.duration]				
darkTime	double	S	Dark current accumulation time, accurate to				
			10ms. [time.duration]				
ccdTemp	float		Temperature measured on the Ccd.				

Table 17: RawCcdExposure Table



LDM-153

Column Name	Data type	Unit	Description [UCD]				
binX	int	pixel	Binning of the ccd in x (row) direction.				
			[meta.number]				
binY	int	pixel	Binning of the ccd in y (column) direction.				
			[meta.number]				
WCS	binary	inary A nominal WCS derives from telescope pointing in-					
			formation (not fitted). [10x8 BYTES].				
flags	int		Flags, bitwise OR tbd [meta.code]				

6.18 RawCcdExposureMetadata

Generic key-value pair metadata for RawCcdExposure.

Table 18:	RawCcdEx	posureMetadata	Table
-----------	----------	----------------	-------

Column Name	Data type	Unit	Description [UCD]				
rawCcdExposureId	long		ld of the corresponding RawCcc [meta.id; obs.image]			RawCcdExposure.	
metadataKey	string						
metadataValue	string						

6.19 RawExposure

Raw exposure (entire exposure, all ccds).

Table 19: RawExposure Table

Column Name	Data type	Unit	Description [UCD]
rawExposureId	long		Primary key (unique identifier.) [meta.id; obs.image]
filterName	char		Filter name. [meta.id; instr.filter]
ra	double	deg	Right Ascension of focal plane center. [pos.eq.ra]
decl	double	deg	Declination of focal plane center. [pos.eq.dec]



LDM-153

Column Name	Data type	Unit	Description [UCD]
skyRotation	double	deg	Sky rotation angle.
altitude	double	deg	Altitude of focal plane center.
azimuth	double	deg	Azimuth of focal plane center.
programId	int		Observing program id (e.g., universal cadence, or one of the deep drilling programs, etc.).
exposureType	byte		Type of exposure (science exposure, dark, flat, etc.).
zenithDistance	float	deg	Zenith distance at observation mid-point. [pos.az.zd]
airmass	float		Airmass of the observed line of sight.
obsStart	timestamp		Start of the exposure, TAI, accurate to 10ms. [time.start]
expMidpt	double		Midpoint for exposure. TAI, accurate to 10ms. [time.epoch]
expTime	double	S	Duration of exposure, accurate to 10ms. [time.duration]
cameraTemp	float	К	Temperature measured of the camera.
mirror1Temp	float	К	Primary mirror temperature.
mirror2Temp	float	К	Secondary mirror temperature.
mirror3Temp	float	К	Tertiary mirror temperature.
domeTemp	float	К	Dome temperature.
externalTemp	float	К	Temperature outside the dome.
dimmSeeing	float	arcsec	Seeing measured by the differential image motion monitor.
pwvGPS	float	mm	GPS-based measurement of precipitable water vapor (PVW).
pwvMW	float	mm	Microwave radiometer measurement of PVW.
flags	int		Flags, bitwise OR tbd [meta.code]

Table 19: RawExposure Table

6.20 CcdVisit



LDM-153

Table 20: CcdVisit Table

Column Name	Data type	Unit	Description [UCD]
ccdVisitId	long		Primary key (unique identifier). [meta.id; obs.image]
visitld	int		Reference to the corresponding entry in the Visit table. [meta.id; obs.exposure]
ccdName	char		Ccd name. [meta.id; instr.det]
raftName	char		Raft name. [meta.id; instr.det]
filterName	char		Filter name used for this exposure. [meta.id; in- str.filter]
nExposures	int		Number of exposures combined to produce this visit.
ra	double	deg	RA of Ccd center. [pos.eq.ra]
decl	double	deg	Decl of Ccd center. [pos.eq.dec]
skyRotation	double	deg	Sky rotation angle.
zenithDistance	float	deg	Zenith distance at observation mid-point. [pos.az.zd]
llcx	int	pixels	FITS pixel coordinates (0.5, 0.5).
llcy	int	pixels	FITS pixel coordinates (0.5, 0.5).
ulcx	int	pixels	FITS pixel coordinates (0.5, 0.5+ySize).
ulcy	int	pixels	FITS pixel coordinates (0.5, 0.5+ySize).
urcx	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5+ySize).
urcy	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5+ySize).
lrcx	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5).
lrcy	int	pixels	FITS pixel coordinates (0.5+xSize, 0.5).
xSize	int		Number of columns in the image.
ySize	int		Number of rows in the image.
obsStart	timestamp		Start of the exposure, TAI, accurate to 10ms. [time.start]
expMidpt	double		Midpoint for exposure. TAI, accurate to 10ms. [time.epoch]
expTime	double	S	Average duration of exposure, accurate to 10ms. [time.duration]



LDM-153

Column Name	Data type	Unit	Description [UCD]
darkTime	double	S	Average dark current accumulation time, accurate
			to 10ms. [time.duration]
ccdTemp	float		Temperature measured on the Ccd.
binX	int	pixel	Binning of the ccd in x (row) direction.
			[meta.number]
binY	int	pixel	Binning of the ccd in y (column) direction.
			[meta.number]
WCS	binary		Precise WCS solution for the Ccd. [100x4 BYTES].
zeroPoint	float		Zero-point for the Ccd, estimated at Ccd center.
seeing	float	arcsec	Mean measured FWHM of the PSF.
skyBg	float	DN	Average sky background.
skyNoise	float	DN	RMS noise of the sky background.
flags	int		Flags, bitwise OR tbd [meta.code]

Table 20: CcdVisit Table

6.21 CcdVisitMetadata

Generic key-value pair metadata for CcdVisit.

Table 21: Ccovisitivietadata Table	Table 21:	CcdVisitMetadata	Table
------------------------------------	-----------	------------------	-------

Column Name	Data type Unit	Description [UCD]
ccdVisitId	long	[meta.id; obs.image]
metadataKey	string	
intValue	int	
doubleValue	double	
stringValue	string	

6.22 Visit

Defines a single Visit.



LDM-153

Latest Revision 2019-06-27

Column Name	Data type	Unit	Description [UCD]
visitld	int		Unique identifier. [meta.id; obs.image]
filterName	char		Filter name. [meta.id; instr.filter]
nExposures	int		Number of exposures combined to produce this visit.
ra	double	deg	RA of focal plane center. [pos.eq.ra]
decl	double	deg	Decl of focal plane center. [pos.eq.dec]
skyRotation	double	deg	Sky rotation angle.
altitude	double	deg	Altitude of focal plane center.
azimuth	double	deg	Azimuth of focal plane center.
programId	int		Observing program id (e.g., universal cadence, or one of the deep drilling programs, etc.).
exposureType	byte		Type of exposure (science exposure, dark, flat, etc.).
zenithDistance	float	deg	Zenith distance at observation mid-point. [pos.az.zd]
airmass	float		Airmass of the observed line of sight.
obsStart	timestamp		Start of the exposure at the fiducial center of the focal plane array, TAI, accurate to 10ms. [time.start]
expMidpt	double		Midpoint for exposure at the fiducial center of the focal plane array. TAI, accurate to 10ms. [time.epoch]
expTime	double	S	Average duration of exposure, accurate to 10ms. [time.duration]
cameraTemp	float	К	Temperature measured of the camera.
mirror1Temp	float	К	Primary mirror temperature.
mirror2Temp	float	К	Secondary mirror temperature.
mirror3Temp	float	К	Tertiary mirror temperature.
domeTemp	float	К	Dome temperature.
externalTemp	float	К	Temperature outside the dome.
dimmSeeing	float	arcsec	Seeing measured by the differential image motion monitor.

Table 22: Visit Table



LDM-153

Table 22: Visit Table

Column Name	Data type	Unit	Description [UCD]
pwvGPS	float	mm	GPS-based measurement of precipitable water va-
			por (PVW).
pwvMW	float	mm	Microwave radiometer measurement of PVW.
flags	int		Flags, bitwise OR tbd [meta.code]

6.23 VisitMetadata

Visit-related generic key-value pair metadata.

Table 23: VisitMetadata Table

Column Name	Data type Unit	Description [UCD]
visitld	int	Id of the corresponding Visit. [meta.id; obs.image]
metadataKey	string	
metadataValue	string	

6.24 Visit_To_RawExposure

Mapping table: Visit to raw Exposure.

Table 24: Visit_To_RawExposure Table

Column Name	Data type Unit	Description [UCD]
visitld	int	Pointer to entry in Visit table. [meta.id; obs.image]
rawExposureId	long	Pointer to entry in RawExposure table. [meta.id;
		obs.image]

6.25 prv_ProcHistory

This table produces unique procHistorylds. The id changes each time something changes in the provenance. It is not linked to any other table. Because it is recording the time, it can serve as a 'snapshot'. E.g., based on the time we can find out which configurations were valid

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Latest Revision 2019-06-27

at that time, what was executed at that time etc. It also serves as a 'flag' that something has changed.

Table 25: prv_ProcHistory Table

Column Name	Data type Unit	Description [UCD]
procHistoryld	long	Unique id [meta.id; src]
theTime	timestamp	Time when this procHistory id was created.
description	text	Description what has changed. This is optional.

6.26 prv_Pipeline

This table defines all LSST Pipelines. One row per pipeline.

Table 26: prv_Pipeline Table

Column Name	Data type Unit	Description [UCD]
pipelineId	int	Unique id [meta.id; src]
pipelineName	string	Pipeline name. [meta.id; src]

6.27 prv_cnf_Pipeline

This table defines all configurations for all pipelines.

Column Name	Data type Unit	Description [UCD]
pipelineCnfld	int	Unique id [meta.id; src]
pipelineld	int	Id of the pipeline this configuration is for.
validityBegin	timestamp	Time when this configuration started to be valid.
validityEnd	timestamp	Time when this configuration stoped being valid.
notes	string	Notes/description useful to keep with this config-
		uration.



LDM-153

6.28 prv_Task

This table defines all tasks for all pipelines.

Table 28: prv_Task Table

Column Name	Data type Unit	Description [UCD]
taskld	int	Unique id [meta.id; src]
taskName	string	Name of the task.

6.29 prv_cnf_Pipeline_Tasks

This is a helper table for prv_cnf_Pipeline, it defines what tasks a given configuration of a pipeline consists of, and what the order is. If tasks are arranged hierarchically, parentTaskId determines which parent task given task belongs to. For tasks that do not have a parent task, parentTaskId is set to NULL. Positions should be numbered starting with 1, and are relative to its parent task.

Column Name	Data type Unit	Description [UCD]
pipelineCnfId	int	
taskld	int	Id of the corresponding task.
parentTaskld	int	ld of the parent task, or NULL if there is no parent task.
taskPosition	int	Position of the task in the pipeline. Starts with 1.

6.30 prv_cnf_Task

This table defines all configurations for all tasks. Note that occasionally manual patching will be required, leading to more than one configuration (the default one, and the patch). This is achieved through taskCnfVersion column.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Column Name	Data type Unit	t Description [UCD]
taskCnfld	int	Unique id [meta.id; src]
taskld	int	Id of the corresponding task.
validityBegin	timestamp	Time when this configuration started to be valid.
validityEnd	timestamp	Time when this configuration stoped being valid.
taskCnfVersion	int	Version of the config (in case there is more than
		one configuration that is valid for a given validity
		range.
gitSHA	string	We need to capture version of the software used
		by this task. For now we are assuming it is just one
		SHA of one commit in git. In practice this can be
		more complicated, it can span multiple repos etc.

Table 30: prv_cnf_Task Table

6.31 prv_cnf_Task_Columns

This table defines which tables+columns are altered by a given task. One row per table+column.

Table 31: prv_cnf_Task_Columns Table

Column Name	Data type Unit	Description [UCD]
taskCnfld	int	If of the corresponding task configuration.
tcName	text	Tableandcolumnpair.Format:'. <column>'.'.*'is allowed toindicate all columns in a table.</column>

6.32 prv_cnf_Task_Files

This table defines which files are altered by a given task. One row per file. This table can be trivially extended should we capture which sections of files are altered.



LDM-153

Table 32: prv_cnf_Task_Files Table

Column Name	Data type Unit	Description [UCD]
taskCnfld	int	If of the corresponding task configuration.
fileUrl	text	url that uniquely locates the file.

6.33 prv_cnf_Task_KVParams

This table keeps parameter values for tasks. One row per parameter. For now everything is kept as strings (not efficient).

Column Name	Data type Unit	Description [UCD]
taskCnfld	int	If of the corresponding task configuration.
theKey	string	Unique key.
theValue	string	Value for the given key.

6.34 prv_Node

This table defines nodes. One row per node.

Table 34: prv_Node Table

Column Name	Data type Unit	Description [UCD]
nodeld	int	Unique id [meta.id; src]
nodeName	string	Name of the node.

6.35 prv_cnf_Node

This table defines all configurations for all nodes.


LDM-153

Column Name	Data type	Unit	Description [UCD]
nodeld	int		ld of the node this configuration is for.
validityBegin	timestamp		Time when this configuration started to be valid.
validityEnd	timestamp		Time when this configuration stoped being valid.
ір	string		IP address (just a silly varchar for now)
OS	string		Operating system name and version.
cores	int		Number of cores.
ram	int		Size of memory [GB].

Table 35: prv_cnf_Node Table

6.36 prv_DataBlock

This table defines blocks of data. A block of data is a group of ids from the same table that are processed together using the same configuration.

Table 36: prv_DataBlock Table

Column Name	Data type Unit	Description [UCD]
blockId	long	Unique id [meta.id; src]
tableName	string	Name of the table this data block is part of.

6.37 prv_RowIdToDataBlock

This table defines which rows belong to a given data block.

Table 37: prv_RowIdToDataBlock Table

Column Name	Data type Unit	Description [UCD]
theld	long	The id of one data element. Note that we are not
		enforcing strict foreign key constraint because this
		will point to different tables.
blockId	long	Id of the block a given row id corresponds to.



LDM-153

6.38 prv_TaskExecution

This table keeps information about all tasks ever executed. Since the configuration of the system is not allowed to change while a tasks is running, we are not keeping a time range here, but instead we just keep the time of when the task started. It might be a good idea to keep the time of the middle of task execution: endTime-startTime/2 to reduce changes of running into an issue with time synchronization between different machines. This table is one of the most important parts of provenance - it links tasks executions with nodes and processed groups. Occasionally manual patching will be required, which will lead to more than one valid configuration of a given task. TaskCnfVersion indicates which version should be used for a given task execution.

Column Name	Data type Unit	Description [UCD]
taskExecId	long	Unique id [meta.id; src]
taskld	int	Id of the task that is executed.
nodeld	int	Id of the node where the task is executed.
theTime	timestamp	The time when the task execution was started.
taskCnfVersion	int	Version of the task configuration. Typically there is
		only one, in some rare cases when manual patch-
		ing in required, we can end up with more than one
		valid config version.

Table 38: prv_TaskExecution Table

6.39 prv_TaskExecutionToInputDataBlock

This table maps tasks executions to input DataBlocks. Each block is typically processed by multiple task executions, and each task execution may process multiple data blocks, so it is many-to-many.

Column Name	Data type Unit	Description [UCD]
taskExecId	long	Id of the task execution.
blockId	long	Id of the block a given task execution uses an input
		or NULL.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



6.40 prv_TaskExecutionToOutputDataBlock

This table maps tasks executions to output DataBlocks. Note that each task execution may output multiple data blocks. There is one entry here for each task execution - output block pair.

Table 40: prv_TaskExecutionToOutputDataBlock Table

Column Name	Data type Unit	Description [UCD]
taskExecId	long	ld of the task execution.
blockId	long	Id of the block produced by a given task execution
		or NULL.

6.41 sdqa_ImageStatus

Unique set of status names and their definitions, e.g. 'passed', 'failed', etc.

Column Name	Data type	Unit	Description [UCD]
sdqa_imageStatusIc	short		Primary key
statusName	string		One-word, camel-case, descriptive name of a pos-
			sible image status (e.g., passedAuto, marginally-
			PassedManual, etc.)
definition	string		Detailed Definition of the image status

6.42 sdqa_Metric

Unique set of metric names and associated metadata (e.g., 'nDeadPix';, 'median';, etc.). There will be approximately 30 records total in this table.

Table 42:	sdqa_	Metric	Table
-----------	-------	--------	-------

Column Name	Data type Unit	Description [UCD]
sdqa_metricld	short	Primary key.

Continued on next page



LDM-153

Table 42: sdqa_Metric Table

Column Name	Data type Unit	Description [UCD]
metricName	string	One-word, camel-case, descriptive name of a pos-
		sible metric (e.g., mSatPix, median, etc).
physicalUnits	string	Physical units of metric.
dataType	char	Flag indicating whether data type of the metric value is integer (0) or float (1).
definition	string	

6.43 sdqa_Rating_ForAmpVisit

Various SDQA ratings for a given amplifier image. There will approximately 30 of these records per image record.

Column Name	Data type Unit	Description [UCD]
sdqa_ratingId	long	Primary key. Auto-increment is used, we define a
		composite unique key, so potential duplicates will
		be captured.
sdqa_metricId	short	Pointer to sdqa_Metric.
sdqa_thresholdId	short	Pointer to sdqa_Threshold.
ampVisitId	long	Pointer to AmpVisit. [meta.id; obs.image]
metricValue	double	Value of this SDQA metric.
metricSigma	double	Uncertainty of the value of this metric.

Table 43: sdga	Rating	ForAmp	oVisit Table	è
	_ · · O			

6.44 sdqa_Rating_CcdVisit

Various SDQA ratings for a given CcdVisit.



LDM-153

Column Name	Data type Unit	Description [UCD]
sdqa_ratingId	long	Primary key. Auto-increment is used, we define a
		composite unique key, so potential duplicates will
		be captured.
sdqa_metricId	short	Pointer to sdqa_Metric.
sdqa_thresholdId	short	Pointer to sdqa_Threshold.
ccdVisitId	long	Pointer to CcdVisit. [meta.id; obs.image]
metricValue	double	Value of this SDQA metric.
metricSigma	double	Uncertainty of the value of this metric.

Table 44: sdqa_Rating_CcdVisit Table

6.45 sdqa_Threshold

Version-controlled metric thresholds. Total number of these records is approximately equal to 30 x the number of times the thresholds will be changed over the entire period of LSST operations (of ordre of 100), with most of the changes occuring in the first year of operations.

Table 45: sdqa_Threshold Table

Column Name	Data type	Unit	Description [UCD]
sdqa_thresholdId	short		Primary key.
sdqa_metricId	short		Pointer to sdqa_Metric table.
upperThreshold	double		Threshold for which a metric value is tested to be greater than.
lowerThreshold	double		Threshold for which a metric value is tested to be less than.
createdDate	timestamp		Database timestamp when the record is inserted.

6.46 LeapSeconds

Based on http://maia.usno.navy.mil/ser7/tai-utc.dat.

The contents of this document are subject to configuration control by the LSST DM Change Control Board.



LDM-153

Column Name	Data type	Unit	Description [UCD]
whenJd	float	d	JD of change in TAI-UTC difference (leap second).
			[time.epoch]
offset	float	S	New number of leap seconds. [time.interval]
mjdRef	float	d	Reference MJD for drift (prior to 1972-Jan-1).
			[time.epoch]
drift	float	s/d	Drift in seconds per day (prior to 1972-Jan-1).
			[arith.rate]
whenMjdUtc	float	d	MJD in UTC system of change (computed).
			[time.epoch]
whenUtc	long	ns	Nanoseconds from epoch in UTC system of
			change (computed). [time]
whenTai	long	ns	Nanoseconds from epoch in TAI system of change
			(computed). [time]

Table 46: LeapSeconds Table

6.47 ApertureBins

Definition of aperture bins (for both the Object and Source tables.)

Table 47: ApertureBins Table

Column Name	Data type Unit	Description [UCD]
binN	byte	A bin in radius at which the aperture measurement
		is being performed.
radiusMin	float	Minimum aperture radii of bin.
radiusMax	float	Maximum aperture radii of bin.

References

[1] **[LSE-163]**, Jurić, M., et al., 2017, *LSST Data Products Definition Document*, LSE-163, URL https://ls.st/LSE-163